



RED ROOSTER

LIFTING

**LHR AIR HOIST & TROLLEY
USER MANUAL**

MODEL - TMH-20T-LHR



FRONT COVER

CONTENTS

INTRODUCTION & SPECIFICATION

SECTION 1: GETTING STARTED

- 1.1 UNPACKING & SPECIFICATION
- 1.2 OPERATION
- 1.3 CHECKS BEFORE USE & HOSE SUPPORT BRACKET
- 1.4 INSTALLATION
- 1.5 TECHNICAL CHARACTERISTICS
- 1.6 HOIST CHECKS
- 1.7 HOIST CONTROLS
- 1.8 ADDITIONAL INSTALLATION INSTRUCTIONS
- 1.9 INSTALLING THE HOIST & TROLLEY
- 1.10 ASSEMBLY & INSTALLATION

SECTION 2: LUBRICATION

SECTION 3: SAFE OPERATION

- 3.1 HOIST OPERATORS & FORESEEABLE INCORRECT USE
- 3.2 SAFETY EQUIPMENT - PPE
- 3.3 LIFTING GEAR BELOW THE HOIST
- 3.4 OPERATIONAL BREAKDOWN OR ACCIDENT

SECTION 4: MAINTENANCE

- 4.1 GENERAL
- 4.2 REPAIRS
- 4.3 TROLLEY VANE MOTOR MAINTENANCE
- 4.4 SILENCING
- 4.5 CHANGING HOIST SILENCERS
- 4.6 CHANGING TROLLEY SILENCERS
- 4.7 FITTING OR REPLACING LOAD CHAIN
- 4.8 TYPES OF CHAIN
- 4.9 EMERGENCY LOWERING
- 4.10 HOIST COMPONENTS AND CHAIN
- 4.11 SERVICE DATA

SECTION 5: LAYING UP THE HOIST

SECTION 6: CHAIN COLLECTORS

SECTION 7: SPEED & LOAD LIMITER ADJUSTMENT

SECTION 8: OPERATIONAL BREAKDOWN / TROUBLESHOOTING THE TMH HOIST

SECTION 9: PERIODIC EXAMINATION & TESTING

- 9.1 EXAMINATION
- 9.2 SIX MONTHLY OFFSHORE INSPECTION
- 9.3 TESTING

SECTION 10: DUTY RATINGS

SECTION 11: EXPLOSION PROTECTION

SECTION 12: TECHNICAL SPECIFICATION

SECTION 13: DATA SHEET

SECTION 14: DRAWINGS AND PARTS LISTS

SECTION 15: ACCESSORIES

SECTION 16: LOG BOOK



INTRODUCTION AND SPECIFICATION

Thank you for choosing the TMH pneumatic chain hoist.

Provided that the hoist is used and maintained in accordance with this manual it will afford you many years of reliable service.

Red Rooster hoists comply with the latest standards and are designed for safe and efficient operation.

Before installing the unit, please ensure that both the personnel responsible for installation, maintenance and operation are fully acquainted with the sections of this manual which are relevant to them.

This manual should be accessible at all times to the relevant person, in case of loss ask your dealer for a new copy.

Specification sheet gives full details of actual model supplied.

The nameplate fitted to the hoist gives the details to identify and gives further information on the hoist.

Notations: The following notations are used throughout this manual.



DANGER

Failure to follow this instruction may result in a dangerous occurrence or fatal injury



CAUTION

Failure to follow this instruction may result in premature wear of the hoist or a component part of the hoist

GETTING STARTED - UNPACKING & SPECIFICATION

1.1 UNPACKING THE HOIST

The hoist will have been packed into a cardboard box, crate or palletised (see weight details in specification). Handling of all models of hoist & trolley will require lifting equipment and shouldn't be moved by hand.

WHEN UNPACKING:

Ensure that both hoist and any ancillary equipment are recovered from the packaging. Small or delicate items may have been packed separately. Check the contents against the supplier's delivery note and advise the supplier immediately of any shortages.

Ensure that the hoist and ancillary equipment are undamaged. If the goods do not reach you in perfect condition, notify your supplier immediately of any damage. Do not proceed with installation if the goods are damaged. **⚠ DANGER**

Ensure that a certificate of Thorough Examination together with a UKCA or a CE Declaration of Conformity is included with the goods. Hand these to a 'responsible person' for safe keeping. Check that the identifying mark (serial number), the Safe Working Load (Rated Load) and that the UKCA or CE marking appears on the hoist or hoist and trolley.

SUPPLIER / MANUFACTURER ADDRESS	Red Rooster Lifting Ltd Nauta House, The Meadows Oldmeldrum, Aberdeenshire UK, AB51 0EZ	Red Rooster Lifting Ltd Unit 26 Kelvin Way Trading Estate Kelvin Way, West Bromwich West Midlands, U.K. B70 7TW
TEL NO	01651 872101	0121 525 4162
MODEL	TMH-20T-LHR	
SERIAL NO		
SWL	20 TONNE	
DATE OF PURCHASE		

NAME PLATES

The name plate gives important information which must be retained. Hoist serial number, SWL, model, air pressure, air flow, hoist rating, chain size, speed, year of manufacture and the manufacturers name and address.

UK Ex / ATEX - Explosive protection

In the UK the use of non-electrical equipment in a hazardous area is covered by 'Products Intended for use in Potentially Explosive Atmospheres 2016 (UK SI 2016 No 1107 as amended by UK SI 2019 No 696)

In Europe and several other parts of the world the use of non-Electrical equipment in a hazardous area is covered by the ATEX Directive 2014/34/EU.

The main standards covering both the UK Ex and ATEX are currently the same: BS EN 80079-36, BS EN 80079-37, BS EN 1127-1 and BS EN 1127-2.

Standard hoists are suitable for use in ZONE 2 Gas areas certified as Ex Group II 3 G Ex h IIB T4 Gc
Standard hoists are suitable for use in ZONE 22 Dust areas certified as Ex Group II 3 D Ex h IIIB T135°C Dc

With extra protection can be used in ZONE 1 Gas areas certified as Ex Group II 2 G Ex h IIB T4 Gb
With extra protection can be used in ZONE 21 Dust areas certified as Ex Group II 2 D Ex h IIIB T135°C Db

Further protection allows the hoist to work in ZONE 1 Gas areas certified as Ex Group II 2 G Ex h IIC T4 Gb
Further protection allows the hoist to work in ZONE 21 Dust areas certified as Ex Group II 2 D Ex h IIIC T135°C Db
(not suitable for TCR Mini or TCS range, IIC or IIIC areas)

The following models can also be rated for mining (Ex Group I M2 Ex h I Mb) – TCR-500 to TCR-2000/2 and TMH models. These hoists can be used according to Equipment Group I Category M2 where equipment is intended to be de-energised in the event of an explosive atmosphere.

The TCR-250, TCR-500/2, TCS-500 and TCS-980/2 models cannot be rated for mining.

CERTIFICATION

All new hoists are supplied with standard certification: Thorough Examination, EU or UKCA Declaration of Conformity, which can include either ATEX or UK Ex certification where required. Other documentation is available by agreement.

IN THE EVENT OF ANY PROBLEMS OR SHOULD YOU REQUIRE ASSISTANCE CONTACT THE SUPPLIER AS DETAILED ABOVE QUOTING THE HOIST MODEL AND SERIAL NUMBER.

PACKAGING MATERIALS SHOULD BE RECYCLED OR DISPOSED OF ACCORDING TO LOCAL REGULATIONS.


GETTING STARTED - OPERATION

1.2 OPERATION

Red Rooster pneumatic hoists and trolleys are designed for the lifting and lowering of loads within the capacity of the model selected. The range of hoists and trolleys can be UKCA, or CE marked and conform with 'Supply of Machinery (Safety) Regulations 2008 (As they apply to machinery being supplied in or into Great Britain from 1st January 2021) for UKCA marking and also the Machinery Directive 2006/42/EC for CE marking. At present both the UK and EU use the same standards with BS EN 14492-2 being the main standard for powered hoisting equipment.

Our range of hoists and trolleys are available as hook suspension units, trolley mounted, built into low headroom units and cranes. Nearly all hoist models are also available as Ex ZONE 1 or 2 hoists for use in hazardous areas, with corrosion protection, and can work in temperatures of -20°C to +60°C. When used outdoor or offshore hoists should be protected against the weather and examination and maintenance interval should be reduced.

Our hoists and trolleys are extremely robust being developed over many years in the harshest of environments and will require little maintenance if kept lubricated on a regular basis. Noise levels can be found in the technical specification and as motor lubricating oil is supplied through the filter lubricator fitted to the hoist there will be a small amount of oil escaping into the atmosphere through the exhaust air: this can be piped away or collected using an exhaust cleaner. In certain circumstances and temperatures there is a danger of icing of the motor and exhaust silencer. This can be prevented by using an anti-icing lubricant such as Silkair or by fitting a dryer to the air supply to remove moisture from the air supply. Some anti-icing oil may damage air hoses and the o-ring in the hoist valve. ⚠ **CAUTION**



Images for illustration purposes only

1	Trolley wheels with sealed bearings (to suit flat or tapered beams)
2	Anti-tilt rollers (can be set to suit flange)
3	Gear box
4	Air motor
5	Control valve
6	Silencers (low noise levels)
7	Load bar (wide range to suit beam)
8	Lock nuts
9	Split pin
10	Adjusting spacers / washers (for easy adjustment)
11	Buffers (standard on UK Ex / ATEX units)
12	Link plate (to suit all Red Rooster hoists)
13	Lift points in side plates for shackles

GETTING STARTED - CHECKS BEFORE USE & HOSE SUPPORT BRACKET

1.3 CHECKS BEFORE USE

These checks should be carried out during installation and on a frequent and regular basis thereafter. If the hoist is used daily then it is recommended that they are carried out daily as the checks take only minutes to complete and not only help avoid repair bills but significantly reduce the possibility of an accident or dangerous occurrence. Thoroughly examine the equipment prior to installation to ensure that no damage has occurred during transit. Hoists and trolleys should not be altered in any way without contacting Red Rooster for clearance, as this may affect the certification of the unit.

AIR SUPPLY CHECKS:

- Inlet pressure: 4 to 6 bar (there will be pressure losses across the air set and on long hoses) The supply pressure should not exceed 7 bar as this may affect the load limiter.
- Air flow: Check air flow requirement and minimum hose diameter also check that small bore fittings are not strangling the air flow.
- Keep the lubricator topped up with a light turbine oil (ISOVG3256).
- The filter should be checked regularly and manual units drained of water as required.
- **THE AIR HOSE SHOULD BE SUPPORTED SO THAT THE WEIGHT OF HOSE IS NOT HANGING FROM THE AIR SET AND FITTINGS. THE AIR SET IS NOT DESIGNED TO SUPPORT THE WEIGHT OF THE HOSE. SEE PAGES 7 AND 12 IF A HOSE SUPPORT BRACKET AND MANIFOLD IS FITTED TO THE HOIST.**
- The air supply should be clean and relatively dry. Where the compressor produces a lot of water action should be taken to remove the excess water.
- Check air connection size and type are compatible.
- Check security of air hose connection.

AIR SUPPLY CONNECTION:

Every installation is different, so the correct method of supporting the air hose should be reviewed while installing the hoist. This needs to take into account the weight and size of the hose, obstructions both at deck and hoist level, connections, operating conditions and any likely movement of the hoist and air hose.

The fittings and filter lubricator are not designed to take the weight of the hose.

If the air supply hose length is over 10 metres the hose ID should be increased to the next size.

AIR SUPPLY:

Vane type air motors are designed to function using clean, dry, lubricated air. The installation of an 'in line' air service unit although essential cannot in itself compensate for serious contamination in the air supply. When operating the compressor in moist (humid) or dusty atmospheres seek the advice of your compressor supplier with regard to the fitting of a dryer and filter. **⚠ CAUTION**

AIR PRESSURE:

The hoist is designed to operate best in the pressure range of 5 to 6 bar (72 to 90 p.s.i). The speeds quoted on the manufacturer's literature are obtainable only at 6 bar (90 p.s.i) inlet pressure. The hoist will operate at much reduced speed at pressures below this figure.

AIR FLOW:

Refer to the hoist data sheet, to select the hose diameter which ensures adequate air flow. Failure to provide adequate airflow will result in a pressure drop in the supply line and cause the hoist to stall and the brake to apply until the pressure increases. In addition, the brake will not release cleanly and will overheat. (Although not in itself a hazard [the brake will fail safe] it may prove frustrating to the operator and a hazard may arise as a consequence.) **⚠ CAUTION**

HOSE SUPPORT BRACKET:

Where a hose support bracket and manifold have been fitted to the hoist to take the weight of an air supply hose, several checks must be done.

- Check the hose hangs freely and does not interfere with the hoist chain.
- Check the hose is clear of the load to be lifted.
- Check the pendant hose is not obstructed by the air supply hose.
- Check the air hose is supported by the hose clamp / former / festoon system.



DANGER

- DO use exclusively correctly rated and certified pneumatic hoses and fittings in the air supply line.
- DO support the air line up to the hoist, as the fitting and filter / lubricator are not designed to take a load and may not support the weight of the hose.
- DO maintain the internal diameter (as per the table throughout the supply length) or reduce from the larger diameter to the smaller diameter in the direction of the hoist.
- DON'T use hydraulic fittings. These often have a reduced orifice size resulting in a down line drop in air pressure.
- DON'T increase from smaller to larger diameter or insert a length of smaller diameter hose in the supply line as this will result in reduced flow and pressure.
- DON'T create low points in the air supply line where water may be trapped (or if unavoidable install a drain tap).
- DON'T rely on pneumatic fittings to support airlines; they are not designed for this purpose.
- DON'T shorten the pendant by forming a loop or a coil. This will prevent the strainer wire from supporting the pendant and will cause the hoses to become detached or kinked.

GETTING STARTED - INSTALLATION & TECHNICAL CHARACTERISTICS

1.4 HOIST ASSEMBLY

Normally our hoist or hoist and trolleys will arrive complete ready to be fitted into position, but sometimes for transportation it may be necessary to disconnect the chain collector, trolley or the pendant control system.

- Chain collectors will be supplied with the necessary bolts and fittings to assemble on site along with any safety slings as shown in section 1.8 and chain collectors in section 7.4.
- Due to the size of some trolleys it is easier to ship split from the hoist, the trolley GA drawings show the load bar and top eye details for refitting and the control and supply air lines are numbered or colour coded for re-connection.
- When lifting into position either use the lifting points on the hoist or hoist and trolley, if the hoist does not have lifting points fitted securely fit slings to the body of the hoist or use the top hook if possible. Do not lift by the controls, valves, or the air set.



DANGER

MOUNTING THE HOIST

The air hoist is designed as a LIFTING MACHINE and as such is designed exclusively for the lifting loads vertically. Non vertical lifting will result in premature wear of the chain and chain guide and may result in damage to the limit arms or a failure of the limit arms to operate. The trolley is designed to move loads along a runway beam or swing jib. It must be correctly adjusted for the flange width and thickness.

- Site the hoist immediately above the load which is to be lifted.
- Ensure that the point from which the hoist is suspended has been designed and tested to at least the same safe working load as the hoist itself.
- Ensure that the suspension point or shackle fits snugly into the bowl of the hoist top hook and that the safety catch closes to prevent escape.
- Use only certified lifting gear with a SWL in excess of the load to be lifted to connect to the load itself.
- Ensure that the lifting gear fits snugly into the bowl of the hoist bottom hook and that the safety catch closes to prevent escape.
- Ensure that the control length (pendant or cords) is adequate to allow the operator to stand away from the load, in a safe and secure position with the cords or pendant at waist height.

TROLLEY ASSEMBLY

- Thoroughly examine the equipment prior to installation to ensure that no damage has occurred during transit,.
- Check the wheel profile matches the beam.
- Never use a damaged trolley.
- Match the trolley to the SWL of the beam and the type of hoist to be fitted.
- Check the load bar nuts are tight and the link plate in the centre of the load bar.
- Trolleys should be cleaned in a dry clean area.
- Do not side load the trolley.

TROLLEY CHECKS

The contents of this section are designed for the guidance of personnel using push or geared trolleys.

- Ensure that the trolley is set to the correct size for the beam.
- Ensure the runway is fitted with adequate end stops.
- Ensure the runway load path is clear of obstructions.
- Ensure that the trolley tie bars are correctly secured.

GETTING STARTED - INSTALLATION & TECHNICAL CHARACTERISTICS

1.4 CLOSE HEADROOM WORKING

The lower hook of the TCR / TCS / TMH hoist includes a swivel arrangement. This allows the load to turn without twisting the chain. However, when repeatedly handling loads with the bottom hook close to the hoist, especially when rotation of the load is prevented, there is tendency for the chain to attempt to enter the guide at an angle. This is particularly pronounced on two fall units. If this problem is noticed when doing a trial lift, a high quality ball bearing swivel should be mounted below the bottom hook of the hoist.

CHAIN COLLECTORS

If the hoist has been supplied with a chain collector bag or bucket, and the chain has been stored within it during shipment, remove all the chain from the collector by hand, and remove any knots or twists. In all cases carefully feed the chain over the load wheel allowing it to fill the collector without any interference as it emerges from the wheel. This way the collector will fill normally. If the chain within the collector is disturbed great care must be taken the next time that the chain is fed out of the collector to ensure that it is not twisted or knotted. Chain bags and buckets are fitted with one or two brackets depending on the model and HOL of the hoist. **⚠ DANGER** See additional instructions (Section 6) for large collectors.

1.5 TECHNICAL CHARACTERISTICS

The WLL of the hoist and trolley will be marked on the hoist / trolley name plate and also in the hoist specification supplied. The reactions on the powered hoist on the support, runway beam or crane should have been taken into account in the design of the structure. The structure should be at least 25% stronger than when using manual equipment due to the shock loading applied by the operational speeds and the starting and stopping of the hoist.

All Red Rooster hoists are fitted with the following safety features

- Overload limiter
- Upper and lower mechanically operated travel limits. These are ultimate stops and should not be used to stop the hoist on a regular basis.
- The disc brake is spring applied so when the controls are not operated or in the event of loss of air supply the brake is applied holding the load in position.
- On pendant controlled hoists an emergency stop button is fitted which connects to a normally open valve either located in the hoist valve chamber or connected to the hoist. When the emergency stop button is pushed or if the air supply to the hoist is cut off then the valve will close stopping the hoist.
- Red Rooster hoists have a 5:1 factor of safety.

GETTING STARTED - HOIST CHECKS

1.6 HOIST CHECKS BEFORE USE

HOIST CHECKS (AIR SUPPLY OFF)

- Hook swivels satisfactorily and the safety catches work correctly.
- Load chain is undamaged and lubricated (light mineral oil).
- The load chain is not twisted through (two fall or more models) and that the load chain passed through the limit lever (All models).
- The load chain anchor is sound (both live and slack end).
- Check for damage to the hoist, pendant and control lines.
- Do not operated below -20°C or above 60°C without contacting Red Rooster.

HOIST CHECKS (AIR SUPPLY ON)


- The pendant buttons, levers or cords should be smooth to operate and return to neutral when released (hoist stops and does not run on).
- The hoist is run up and down on a regular basis. Where hoists are hanging in a dry and protected area they should be run weekly, where the hoist is outside and not protected it should be checked, lubricated and run daily.
- The emergency stop button / valve operates immediately.
- Upper and lower limit switches / levers work satisfactorily.
- Load chains run smoothly over the pocket wheel.
- The load chain should be examined periodically for cracks, gouges and wear.
- Chain collectors should be checked for security and chain capacity.
- Check chain runs in and out of the chain collector smoothly.
- For hoists with a long drop of chain or a large chain collector a separate suspension point may be required (see section 1.8).
- Cord control hoists should have the toggles marked for raise and lower.
- On cord controls check the spool valve returns to neutral and the hoist stops when the cord is released. (hoist stops and does not run on).
- Check the silencer is not partially blocked by comparing the running speed without load against the speed in the manual. ⚠ **DANGER**

NEVER RELEASE THE EMERGENCY STOP BUTTON UNTIL IT IS SAFE TO DO SO

Hoist swivels satisfactorily.


Hoist safety claws functional and undamaged.

Safety claw



Chain undamaged

Chain not twisted through (two fall models see sketch)



GETTING STARTED - HOIST CHECKS & INSTALLATION INSTRUCTIONS

1.7 HOIST CONTROLS

Air hoists can be controlled by either a pull cord or a pendant control operating the spool valve of the hoist operating raise and lower. The diagram at the bottom of this page shows the set up for both types of control and the location on the hoist body.

Cord or pendant hose lengths should be long enough for the operator to stand away from under the load but still with the cord toggles or the pendant suspended at a height of around 1 metre from the operating level. Where the controls have to be to the side of the hoist or where the operator cannot see the load travelling the full range of the lift a banksman should be appointed to assist the operator using a reliable means of communication.

1.8 ADDITIONAL INSTALLATION INSTRUCTIONS

Hook suspension with long chain drops.

Problem:

When a long heavy chain is fitted, and the 'raise' is pressed with the hoist in an unloaded condition, due to the centre line of the hoist having been affected by the weight of chain, the upper limit switch, may fail to operate. In addition, the slack load chain may on some modules foul the limit lever arms, thus preventing it from returning to the centre (neutral position).

Resolution:

A short length of wire rope, 6mm diameter, is fitted to the hoists and bulldog grips have been supplied.

Suspend the hoist in its final location and with as much chain as possible in use. Apply a small load to the hoist and lift it clear of the ground.


Connect the wire rope sling to the support steel alongside the top hook using bulldog grips.

The tension in this sling should be enough to counteract most of the weight of the slack chain produced in the fully raised position, but it must not be tensioned such that it is carrying any of the load supported by the hoist. i.e. if fitted correctly, in an unloaded condition, the sling will be tensioned with the hoist ALMOST in the vertical position. When the load is applied, the tension in the sling will be slack.

Trolley Resolution:

When a hoist and trolley are fitted with heavy chain or a long drop, a second push trolley can be used in the same way to support the weight.


THE SLING IS NOT CAPABLE OF HOLDING THE LOADS CARRIED BY THE HOIST






GETTING STARTED

**STANDARD HOSE CONNECTION
PENDANT CONTROL OR
HOIST WITH EXTERNAL
EMERGENCY STOP VALVE**




**STANDARD HOSE CONNECTION
CORD CONTROL OR
HOIST WITH INTERNAL
EMERGENCY STOP VALVE**





GETTING STARTED

Air Hose Connection with Hose Clamp and Manifold



* Some hoists are fitted with internal emergency stop valves
 ** The hose clamp can also be fitted to the trolley side plate.

GETTING STARTED - INSTALLING THE HOIST & TROLLEY

- 1.9 RRL trolleys can be plain (non-powered), hand chain (geared) or powered (pneumatic) Hoists can be hook-mounted to the suspension shaft of the trolley, or rigidly mounted to a trolley hanger bracket.

This trolley has been designed for horizontally transporting loads by hand, through manual or pneumatic hoists under normal atmospheric conditions of the work place.

In order to ensure the maximum performance and life from this pneumatic trolley it is essential that the following points are strictly observed.

- The trolley air motor may be operated in any attitude provided adequate lubrication is supplied.
Being totally enclosed they can be used in any environment within the temperature limits of -20°C to +60°C.
- The maximum working pressure for the air motor is 7 bar (100psi)
- Be sure to adjust the anti-tilt rollers to the highest position possible in the slot to leave the minimum clearance between the underside of the beam and the top of the roller.
- Axial loads should be kept to a minimum.
- Care should be taken when fitting drive components to the shaft, that excessive force is **not used**.
This will upset the rotor alignment which has been kept to a minimum in order to give high motor performance.
- Check the drive pinion / geared wheels are greased.

OPERATION

Plain Trolley The trolley movement is controlled by pushing the load or the hook of the attached hoist.

Geared Trolley Face the hand wheel side of the trolley.
To move left, pull hand chain clockwise.
To move right, pull hand chain counterclockwise,

Pneumatic Trolley The trolley direction is controlled by the pendant buttons or levers.
Face the trolley motor side plate and use the white or black arrows to control the pendant.
The emergency stop buttons stops the trolley.

Trolleys are either delivered assembled for the beam size advised, or assembling but require to be adjusted to the correct beam size.

The lifting points at the top of the trolley above the gearbox should be used for lifting the hoist and trolley into place. Care must be taken not to allow the unit to swing, as the gearbox flange can be damaged and broken if it is allowed to impact against steelwork etc. If contact is made, the flange should be inspected and removed from service for repair.

MOUNTING

Make certain the hoist is properly installed. A little extra time and effort in doing so can contribute a lot toward preventing accidents or injuries and will help achieve the best service possible.

When installing a trolley on a beam, measure the beam flange width and temporarily install the trolley to determine the exact distribution and arrangement of the spacers.

HOOK MOUNTED HOIST

After final trolley installation place hook over suspension shaft or eye. Make sure hook latch is engaged.

If the hoist is suspended by a top hook, the trolley suspension shaft should rest completely within the saddle of the hook and be centred directly between the side plates.

RIGID / EYE MOUNTED HOIST

Mount hoist to trolley and temporarily install on beam to determine exact distribution of spacers to centre the top eye.

After installation, operate trolley over entire length of beam with a capacity load suspended 10 to 15cm off the floor.




GETTING STARTED - INSTALLING THE HOIST & TROLLEY

1.9 FITTING TROLLEYS IN LOCATION

MOUNTING FROM THE RAIL END

Air trolleys can either be fitted to the runway beam or swing jib in two ways.


- 1) By removing the end stop from the beam and sliding the trolley which is already set for the flange size on to the beam and then re-fitting the end stop.




MOUNTING BY DISASSEMBLING THE MAIN TROLLEY BODY

- 2) By opening the trolley up so that the inner part of the wheels will pass over the beam flange and then sliding the trolley side plates back along the shaft, refitting the spacers, washers and nuts and then tighten up the nuts and check the wheel setting. Be sure to firmly support the parts during reassembly from the bottom side so that the side-plates are not twisted or otherwise shifted. On completion of reassembly, be sure to confirm that various shafts, nuts, lock pins and split pins are properly fastened without any slack and have not been loosened.

PLAIN SIDE PLATE
ASSEMBLY




MOTOR SIDE PLATE
ASSEMBLY



GETTING STARTED - INSTALLING THE HOIST & TROLLEY

1.9



SETTING THE TROLLEY (up to 3 tonne)

- 1) Slide the hook receiving part or link plate near the suspended shaft centre and grease the shaft.
- 2) Distribute the spacer rings and adjusting collars equally to either side of the link plate, in order to obtain the dimensions between the wheels, corresponding to the beam width plus 2 or 3mm.
- 3) Distribute on each side of the side plates, washers and adjusting collars that are remaining and screw a nut on each extremity.
- 4) Tighten the nuts and lock nuts on the load bar and check the clearance between the beam flange and the wheel flange.
- 5) Position the tie-rods, anti-tilt rollers, washers and nuts into the slots in each of the side plates. Set to give the minimum amount of clearance between the underside of the beam and the top of the anti-tilt roller. Then tighten the nut against the roller and side plate and re-check the wheel setting.

SETTING THE TROLLEY (over 3 tonne)

- 1) For trolleys with capacities greater than 3 tonnes, verify that the dimension between the wheel flanges is correct (beam width plus 3 or 4mm), if not adjust the number of washers and spacers between the side plates to obtain the required dimension, by distributing the spacers and washers equally to each side of the link.
- 2) Loosen the suspended shaft nuts and the connecting tie rod nuts, to separate the side plates enough to be able to put the trolley onto the beam.
- 3) Tighten the nuts and lock nuts on the load bar and check the clearance between the beam flange and the wheel flange.
- 4) Position the anti-tilt rollers, tie rods and nuts in the slots provided in the side plate to give the minimum clearance between the underside of the beam and the trolley wheel. Then tighten the nuts against the roller on the inside of the trolley side plate, making sure that the side plates are not bent. When this is done re-check the wheel setting.

GETTING STARTED - INSTALLING THE HOIST & TROLLEY

1.9

DANGER

TROLLEY CHECKS

- Ensure the runway beam is fitted with adequate end stops which strike the buffer/anti-drop plate on the trolley.
- Ensure the runway load path is clear of obstructions, flat and in good condition.
- Ensure the teeth from the pinion fit correctly into the rack on the beam (if fitted)
- The air supply hose should not be suspended from the hoist without support. Where feasible, a taut wire or a festoon system should be fitted to allow the hose to run along the beam, without loading the air set or fittings.
- The hoist connection plate should be in the centre of the load bar with an equal amount of spacers each side.
- When a trolley has been opened/split for adjusting or fitting, the load bar and tie bar nut should be re-tightened.
- The trolley side plates should be parallel to the beam flange when the nuts are tight .
- Do not use the beam end stops to stop the trolley on a regular basis. It is a safety measure.


DANGER **CAUTION**

- DO use exclusively correctly rated pneumatic hoses and fittings in the air supply line.
- DO maintain the internal diameter (as per the table throughout the supply length) or reduce from the larger diameter to the smaller diameter in the direction of the hoist.
- DO support the airline up to the hoist, as the fittings and filter/lubricator are not designed to take a load and may not support the weight of the hose.
- DON'T use hydraulic fittings as these tend to have a reduced orifice size resulting in a down line drop in air pressure.
- DON'T increase from smaller to larger diameter or insert a length of smaller diameter hose in the supply line as this will result in reduced flow and pressure.
- DON'T create low points in the air supply line where water may be trapped (or if unavoidable install a drain tap)
- DON'T shorten the pendant by forming a loop or coil. This will prevent the strainer wire from supporting the pendant and will cause the hoses to become detached or kinked.
- DON'T allow the air hose to hang from the air set. Neither the air set or fittings are designed to take the weight of the hose.

OPERATION - LOW HEADROOM & ULTRA LOW HEADROOM TROLLEY



1.9

- The LHR and ULHR trolley should only be used on straight runway beams. Special units are available for curved beams designed to suit the radius.
- LHR and ULHR trolleys are usually designed for a set beam size but can be made adjustable if required.
- LHR and ULHR units are available as standard or UK Ex / ATEX versions and with our in-house design team special units can be manufactured to suit your requirements.
- LHR units are also available as articulated units or with rack and pinion drive or beam brake.



ASSEMBLY AND INSTALLATION - RACK & PINION TROLLEY

- 1.10
- The fitting of a rack and pinion trolleys is very similar to a standard air trolley with the addition of the pinion adjustment to mesh with the rack on the runway beam or swing jib.
 - The four bolts on the driven and non-driven adjusting plates should be slackened to allow the plates to drop down to the maximum rack clearance.
 - Fit the trolley on to the beam as per the standard instructions.
 - Push the adjusting plates up so that the pinion meshes with the rack on the beam, the lower down by 1 to 1.5mm.
 - Slightly tighten the four bolts on both adjusting plates.
 - Check the pinion shaft is parallel with the beam flange and adjust if necessary.
 - Tighten up the eight bolts
 - Check the clearance has not changed between the pinion and the rack.
 - Function test with a load.
 - Re-check the security of all nuts and bolts on the trolley.



ASSEMBLY AND INSTALLATION - BEAM BRAKE TROLLEY


(See standard trolley installation instructions)

Air and geared trolleys fitted with a beam brakes are manufactured to fit only the size of beam flange they are designed for. If they have to be moved to another beam then a new beam brake shaft would be required.

Trolleys can either be air powered or gear travel and are based on a standard trolley fitted with blocks or pads to lock the trolley in location when the chain wheel is turned. The chain is then turned the other way to release the trolley.

Fitting of a trolley with a beam brake should be done from the end of the beam with the end stops removed for fitting. It can be difficult to open up the trolley to fit over the beam and then close up again while suspended.

Check operation of beam brake when locked in position. Close beam brake and then try pulling the geared drive chain checking that the trolley does not move.



ASSEMBLY AND INSTALLATION - LHR, ULHR & ARTICULATED TROLLEY

- 1.10
- The fitting of an articulated trolley will depend on the design of the power transfer between the trolley drive wheels. This can either be with a motor gearbox at one side with a transfer shaft across to the geared wheel on the plain side plate or the trolley can have a motor gearbox on both side plates to drive the trolley.
 - The fitting of the trolley on to the beam can either be from the end of the beam or the trolley can be opened up to fit over the beam flange.

MOUNTING FROM THE END OF THE RUNWAY BEAM


- Check the trolley wheel setting against the runway beam flange size (the setting should be as per the standard trolley setting)
- Remove the runway beam end stop and slide the assembled trolley on to the runway beam past the position for the end stop and then re-fit the end stop
- Check the wheel setting and connect the air supply then function check the trolley without load along the straight and curved sections of the runway beam.
- If the trolley runs along the working area without problem lift the SWL for the hoist and trolley and travel along the runway beam checking for any problems travelling around the curves and over joints.

MOUNTING BY DISMANTLING THE MAIN TROLLEY BODY (TRANSFER SHAFT) - CAUTION

- If the trolley is fitted with a transfer shaft and the load bars are made for a set size, several parts such as the transfer shaft, gears, and bolts will have to be removed at ground level when opening the trolley and then refitted when the trolley side plates are positioned at either side of the runway beam.
- Position one or two hoists at either side of the runway beam, connect the bottom hooks the lifting points on the trolley side plates and lift the trolley side plates up to a position where the trolley wheels are level with the beam flange.
- While holding the transfer shaft and load bars in position close the plain side plate on to the beam lining up the transfer shaft gears and load bars. Check the security of the shafts, load bars and tie bars.
- Carry out checks and function tests as per item 1

MOUNTING BY DISMANTLING THE MAIN TROLLEY BODY (DUAL MOTORS)

- Where dual air motor are mounted on two trolley side plates this allows for the trolleys to be easily opened up at ground level, lifted up and then closed on to the beam flange.
- Check trolley flange setting matches the runway beam flange
- Position the hoist and trolley under the beam where the hoists is to be installed
- Position two or four hoists above the runway beam and connect the bottom hooks to the lifting points on the trolley side plates.
- Slacken the load bar and tie bar nuts so that the side plates can slide apart, then check the opening between the inside of wheels is wide enough to go past the beam flange.
- Keeping the trolley level lift the trolley wheels up to the level of the beam flange.
- Next push the trolley side plates together, then tighten the nuts on the load bar and tie bars, check all parts are secure.
- Check the trolley wheel setting on the beam (as per standard trolley) and then connect the air supply and function test the trolley without load along the full length of the curved and straight sections of the runway beam.
- Next with the SWL of the hoist and trolley run the trolley along the runway beam checking movement around any curved sections and over joints.



LUBRICATION

2.1

Item	Oil Type	Frequency
Lubricator Unit Main Air Supply	Atlub Medium to light turbine oil ISO VG 32-56 Or any quality airline lubricant (See note 1)	10 to 15 drops per minute Do not allow lubricator to run out of oil
Load Chain	Normal industrial - any light mineral oil Clean areas - wax based, semi setting Food industry - suitable vegetable oil (See note 2)	Weekly / monthly subject to environment / use
Limit Lever Linkages and Anchor pins	No. 2 grease	Monthly or more frequently in aggressive environments
Gearbox (Hoist)	High temperature EP2 grease	Only at major overhaul
Gearbox (Trolley)	Grade VG220	Only at major overhaul
Trolley Drive Pinion	No. 2 Grease	Monthly or more frequently in aggressive environments

Note 1

In all cases oil will be expelled from the hoist and trolley exhaust. The amount discharged is proportional to the delivery rate of the lubricator. In environments where oil in the exhaust cannot be tolerated, the exhaust can be piped away to a safe area, but this requires specialist modification of the hoist (See air service equipment) - CONSULT YOUR DEALER. ⚠ **CAUTION**

Note 2

All Red Rooster hoist chain must be lubricated to prevent wear. ⚠ **DANGER**

Keeping load chain clean and lubricated will greatly increase the lifetime of the chain and prevent costly replacement. Very little lubricant is needed and can be easily applied to the chain by cloth, brush or spray.

Note 3

Geared wheels (air + geared trolley only) - Lubricate exposed trolley drive pinion and wheel teeth. Brush with grease as often as necessary to keep teeth liberally covered. If the grease becomes contaminated with sand, dirt or other worn materials, remove old greases and replace with new grease (standard grease) during monthly or annual inspection. Temperature range of standard grease is -10°C to +50°C. If the trolley is used at temperature below -10°C or above +50°C, consult Red Rooster since some parts shall be changed.


Note 4

Trolley wheel bearings do not need to be lubricated and must be replaced if worn or damaged. Hand chain, used on geared trolleys, does not normally require lubrication.

In areas of high corrosion, plated chain can be used along with special lubricants to prevent corrosion from sea water and spray. Chains used in these areas should be re-lubricated on a regular basis.

NEVER use heavy grease or bitumen based products to lubricate the chain as these will foul the chain guide, idler and load wheels and bearings. ⚠ **DANGER**

Remove dust and water drops on the Load Chain and then apply lubricant. Application of lubrication influences on the life of the Load Chain considerably. Apply the lubricant sufficiently.



SAFE OPERATION - AIR HOIST & TROLLEY

- 3.1 The contents of this section are designed for the guidance of personnel using the hoist. For the most part, they are 'common sense' procedures. Most dangerous occurrences involving lifting machines are not as a result of defect developing in the machine itself but are as a result of an error or act of carelessness by the operator. As such, the vast majority of accidents or dangerous occurrences are avoidable. The operator is responsible for his safety and the safety of others in the area of the hoist.

It is further recommended that only authorised personnel should be permitted to use the hoist and that all staff should be properly trained and have adequate knowledge in both safe use and visual examination.

ALWAYS - follow company procedures, work safely, report faults and comply with regulations.

Operating in cold weather can effect both the equipment and the operator. Fluids do not flow, so allow time to warm up the hoist and trolley. Operators wear increased clothing so vision, hearing and touch could be impaired. ⚠ **DANGER** ⚠ **CAUTION**

DANGER

GUIDELINES FOR PERSONNEL USING AIR HOIST - ALWAYS:

- Read the instruction manual before use.
- Test run the equipment prior to application of a load and ensure that the equipment, including its control and safety devices are functioning correctly.
- Do not touch the hoist body immediately after extensive use, as it may be hot or very cold.
- Do not wear loose clothing (ties, scarves etc.) which may get dragged into the hoist or bottom block.
- Wear safety boots or shoes (together with a safety helmet if lifting overhead).
- Ensure that a positively engaged isolator requiring an appropriate operation to re-engage, is fitted between the air supply and the machine (lever, button or quarter turn valve). The isolator should isolate only the machine itself or where the safety of other machines may be affected by isolation of the machine, all machines affected must be isolated at the same time.
- Large hoists and trolleys have lifting eyes that can be used for handling and installation. Where no lifting eyes are fitted, a sling may be fitted round the hoist body using a choker hitch.
- Ensure that the load is securely supported by certified lifting gear (slings and shackles) with a higher safe working load in the configuration used, than the load to be lifted and that it cannot 'escape' whilst being lifted.
- Stand clear of the load when lifting or lowering and ensure that the point at which you are standing is secure. Do not touch moving chain.
- When there is a brief pause in the lifting operation where the operator lets go of the pendant control, he must stay in the area and make sure the pendant hangs vertically and cannot swing or get blown against anything.
- When there is a longer break in the lifting operation and the load has been landed, then the emergency stop button should be actuated so that a positive action is required before the hoist or hoist and trolley can be operated.
- If the hook is still attached to an item then a sign should be attached to the pendant and depending on the circumstances the power supply locked off.
- Ensure that other personnel cannot enter the immediate area where the lift is taking place.
- Never lift the load higher than necessary.
- Ensure that the control length (cord or pendant) is adequate to allow the operator to stand away from the load in a position to see the load at all stages of lift.
- The pendant should hang from the hoist and not be placed onto objects where the controls could be activated.
- If it is not possible to site yourself in a position where you can see the load at all stages, appoint a 'banksman' to cover the area which you cannot see and establish a reliable method of communication (verbal or hand signals) before starting the lift.
- If you suspect that the equipment is defective or is developing a fault, stop the lifting operation immediately.
- In the event of an emergency make the area safe by returning the load to a rest position, but if this is not possible the area should be cordoned off and the advice of your superior or safety officer sought. Never repair a hoist with the load suspended.
- If it is not possible to lower a load to the ground to make it safe, then a lifting plan must be in place to recover the load or make it safe in case of hoist failure.
- In the case of complex lifting operations a lifting plan must be in place to control the lift stipulating the hoists to be used, operating conditions, operator instructions and the different parts of the lift taking part in the agreed sequence. Carry out a practice lift with a small load if necessary to confirm the lifting operation.
- The starting and stopping of the hoist and taking up of slack chain at high speed can apply high forces which could be higher than the load being lifted. Always operate hoists smoothly and in a controlled manner.
- The attachment points must be capable of withstanding the expected forces.
- External vibration can affect the hoist and can cause damage and wear.
- Do not use the hoist outside in high winds, bad weather conditions, or when temperatures are likely to be outside the operating temperature of the hoist.
- Only use the hoist to make a lift safe when a warning alarm has been activated in the area and then isolate the hoist.
- With trolleys less than 5 tonne SWL the weight of the hose may cause side loading of the trolley and could cause the wheels to come off the beam so the hose should be supported at the beam height to prevent loading the trolley, air set or fittings.

AT ALL TIMES THINK BEFORE YOU ACT - PLAN EVERY LIFT

SAFE OPERATION - HOIST OPERATORS

DANGER

- 3.1
- Hoist operators must be healthy with satisfactory eyesight and not under the influence of alcohol, drugs or medication when operating the hoist.
 - Hoist operators should be trained in the operation of hoists proper rigging procedures for the attachment of loads to the hoist.
 - The operator is always responsible for his own safety and anybody else in the operating area.
 - Always start the lowering or lifting movement slowly and smoothly.
 - When using the hoist jointly with another person, use signals agreed upon at the job site (standardized signals).
 - When using the hoist without chain collector, avoid the slack chain to fall, catch or impact as this can cause hazards.
 - In case of air pressure loss, secure the load and area. Ensure that turning the air supply back on cannot result in a dangerous occurrence.
 - Stop using the hoist in case of abnormal sounds.

SAFE OPERATION - FORESEEABLE INCORRECT USE

DANGER **CAUTION**

- 3.1
- Supporting structures used with this trolley must meet or exceed the design safety factor to handle the rated load, plus the weight of the hoist and attached equipment. This is the customers responsibility. If in doubt, consult a registered engineer
 - Where the supporting steel work transfers a vibration or oscillation through the hoist this can cause increased wear between the links of the load chain.
 - Where the hoist or hoist and trolleys are fitted with lifting points they should only be used for lifting the hoist and trolley, they are not designed to take the full WLL of the hoist.
 - Before carrying out any work on the hoist or trolley the main air should be turned off and the residual are vented or the hoist run to dissipate the air pressure.
 - Do not exceed the stated SWL or duty rating. (Fig. A)
 - Operate the hoist smoothly. Do not suddenly change direction as this may exert both shock loads acceleration forces may well in excess of the weight of the load being lifted.
 - Do not use the hoist to lift / lower / transport personnel. (Fig. B)
 - Only use the hoist to lift a load vertically. It is not designed to pull or drag loads without modification and or a lift plan being used for special lifting operations, such as cross hauling. (Fig. C)
 - Ensure that the load is securely supported by its lifting gear (slings shackles etc.) and that it cannot escape whilst being lifted.
 - Ensure that the lifting assembly (slings, shackles etc.) has a higher safe working load in the configuration used than the load to be lifted.
 - Ensure that the point at which the hoist is to be suspended has an equal or greater safe working load than the hoist.
 - Ensure that the load is free to move and will clear all obstructions.
 - Avoid swinging the load or hook.
 - Do not use the hoist if the chain is damaged, twisted, kinked or worn.
 - Ensure that the load is stable and in balance at starting lifting or setting down as tilting or falling loads can cause accidents.
 - Never allow loads to "fall" into the load chain, causing shock-loading. (Fig. D)
 - Never lock the control elements of the pendant or controls.
 - Never use the chain, hooks or hoist as an electrical ground for welding or electricity.
 - Do not use the limits as a means of stopping the hoist (these are safety devices).
 - Do not use controls as a means of moving the hoist (the pendant is designed to support its own self weight only).
 - Stand clear of the load when lifting and lowering and ensure that the point at which you are standing is safe and secure. (Fig. E)
 - Do not hold onto the load chain when controlling a load (fit a tag to the load if necessary to ensure that the load is controlled).
 - Do not apply a load to the tip of the Bottom Hook or the Hook Latch. (Fig. F)
 - Do not bind a load with the load chain directly. (Fig. G)
 - Do not operate the Load Chain while it is in contact with any sharp edges. (Fig. H)




Fig. A




Fig. B




Fig. C




Fig. D




Fig. E




Fig. F




Fig. G




Fig. H

SAFE OPERATION

 DANGER

3.2 SAFETY EQUIPMENT - PPE

Safe systems of work should be appropriate for the working conditions that the hoist is being used in with method statements stating what the hoist is being used for, the authorisation of staff to operate hoists and the PPE requirements in place. In general overalls, safety shoes, hearing protection and gloves are normal but other sites will require safety glasses and hard hats.


 DANGER

3.3 LIFTING GEAR BELOW THE HOIST


Where lifting gear is connected into the bottom hook of the hoist it should be sized for at least the capacity of the hoist and physically fit well into the body of the hook allowing the safety catch to close.

Where a larger item such as a spreader beam is used this may have an effect on the lifting capacity of the hoist, so the SWL should be reduced to reflect this.

HOW TO SLING THE LOAD PROPERLY



DO NOT CARRY OUT DANGEROUS HOOKING AS SHOWN BELOW



 DANGER

3.4 OPERATIONAL BREAKDOWN OR ACCIDENT

If an unloaded hoist stops working then it should be removed from location and sent for repair if none of the remedies in the trouble shooting guide have an effect.

When the hoist is still holding a load then an additional hoist should be used to take the weight of the load so it can be safely lowered and the faulty hoist removed for repair. If another hoist cannot be used to lower the load it is possible to release the brake by slackening the brake cover screws but this should only be done by a RRL engineer or after discussions with Red Rooster as it is not always possible or safe to do so.

The main air supply line to the hoist should be fitted with an easily accessible valve to cut off the air supply to the hoist in case of emergency or for maintenance. Pendant control hoists also have a main air shut off valve.

There should be a safe access to the hoist to carry out maintenance, inspection and lubrication.

MAINTENANCE

- 4.1 The TMH range of hoists are heavy duty pneumatic hoists and built to require little maintenance if they are kept lubricated and maintained. The maintenance required will depend on daily operating times, the conditions, quality of the air supply and the percentage of the WLL regularly being lifted. The operators daily checks and the monthly maintenance checks are necessary to check the condition of the hoist. Maintenance work should be carried out by trained and qualified personnel. ⚠ **DANGER**

It is recommended that in the case of the TMH hoist and air trolleys inspections are carried out in accordance with the following schedule, although the frequency of the 'six month inspection' should be increased in high risk environments, aggressive environments or where the usage is particularly heavy to between one and three months. ⚠ **CAUTION**

EVERY DAY / WEEK (DEPENDING ON USAGE) ⚠ **CAUTION**

The items listed under 'checks before use' in Section 1 (Getting Started) of the manual should be examined. It is recommended that the lubricator is 'topped up' as a part of this inspection routine.

AT LEAST ONCE PER MONTH FOR HOISTS IN CONSTANT USE OR EVERY THREE MONTHS LIGHTLY USED UNITS

⚠ **DANGER**

LOAD CHAIN - Thoroughly examine throughout its length for wear in the links, corrosion, cracks or distortion. If the wear in the links exceeds that stated in the chart, the chain should be replaced. If there are any visible cracks or distortion the chain should be replaced. Any wear should be measured and checked against section 4.8.

BRAKE - With a load applied check the brake efficiency. If there is any delay in actuation or slippage, the brake is defective and the hoist must be thoroughly overhauled before being returned to service.

HOOKS, SWIVELS AND CLAWS - Examine hooks for wear, deformation (refer to chart), nicks and gouges. Ensure that the hooks swivel smoothly and that the safety claw opens fully and closes under spring tension.

CHAIN ANCHOR PIN - Examine for wear and deformation.

NUTS AND BOLTS - Using suitable spanner and Allen key, check for any loose nuts and bolts.

UPPER AND LOWER LIMIT - Ensure that it functions correctly in both the fully raised and fully (chain lever) lowered positions.

CHAIN COLLECTOR - Check security and condition.

It is recommended that the load chain and linkages are lubricated as part of this inspection routine.

When repairing Red Rooster air hoists only original Red Rooster products should be used.

INSPECTION

- Inspect the gearbox for oil leaks.
- Inspect the drive pinion and wheels for wear, damage and lubrication.
- Check air motor silencers and replace if necessary.
- Check wheel adjustment.
- Check anti-tilt roller setting.
- Check valves and fittings for security and air leaks.
- Check main air line connection for security and air leaks
- Check control lines for security and air leaks

- 4.2 Only minor repairs such as silencers, safety catches, pendant repairs, replacing shorter lengths of load chain and inspections should be done in location after this the hoist should be lowered to ground level and taken to a workshop. ⚠ **CAUTION**

If the hoist is taken out of service it should be sent to an approved repairer to be fully dismantled, repaired and tested. ⚠ **CAUTION**

Only Red Rooster approved parts should be fitted to the hoist but good quality European or Japanese load chain and bearings can be used but other than that only Red Rooster supplied parts should be used. ⚠ **CAUTION**

Hoist and trolleys are heavy along with some parts of some hoist so suitable lifting equipment should be used to dismantle and assemble hoists. ⚠ **DANGER**

TROLLEY VANE MOTOR MAINTENANCE

- 4.3 These motors are made to precise tolerances and it is vital for efficient operation to achieve minimum clearances throughout. Every clearance represents an air leakage path from inlet to exhaust, which will detract from the starting and running characteristics.

The spacing of the rotor is of prime importance in two ways:

- Rotor to end covers (side clearance) (Cs) nominally 0.050mm (0.002").
- Rotor to body casing (top clearance) (Ct) nominally 0.050mm (0.002").

To achieve the side clearance each repair kit has a series of plastic shims, colour coded to different thicknesses.

Purple = 0.025mm (0.001")

Blue = 0.050mm (0.002")

Green = 0.076mm (0.003")

Orange or Brown = 0.102mm (0.004")

This range of vane motors has two styles of rotor locations.

V4 rotor location by one double row bearing in rear cover.

V6 rotor location by one double row bearing in front cover.

ASSEMBLY DETAILS

All parts must be clean and it is recommended that new oil seals and blades are fitted as a matter of course. Press all bearings fully home into their respective covers, pressing only on the outer track to prevent damaging the bearings. On V4 motor fit oil seal retaining circlip and a new oil seal.

Take the location cover for your particular motor i.e. V4 rear cover and V6 front cover.






Provide good support on the inner bearing track, as the shaft fit is very tight, to provide rotor location. Place blade ejector ring central on cover and press rotor/shaft assembly down until there is a clearance. Cs of 0.050mm (0.002") between rotor and cover, check this clearance is even all round the rotor. Fit a blue plastic body gasket cover, lowering the body into position over the rotor assembly, locating on the existing dowels.

NOTE: Ensure the body is the correct way round i.e. port arrows towards the output shaft.

Tighten body bolts and check top clearance, Ct, see Fig. 4. This should be 0.050mm (0.002") if there is a problem with this then reposition and drill for new dowels. Insert second ejector ring, fit new blades, it may be necessary to work the lower ejector ring across in order to fit the opposite blade. Refer to Fig. 5 (axial and clearance, Cs). Measure this by putting a straight edge across the body, then use the feeler gauges in the gap between rotor and body face. This should be made up to 0.050mm (0.002") or as close as possible using the gasket set provided.

Oil inside the motor, ensuring it is free to rotate. On V4 and V6 motors the second cover should slide down into position easily as the second bearing fir is non-locating.

On V6 motors the front oil seal is carried in a separate housing, this should be fitted next, followed by the rear bearing cover and its gasket. On V4 motors the rear bearing cover and its o-ring can now be fitted.





SAFE OPERATION

4.4 SILENCING

The TMH hoist is fitted with an internal silencer; the noise output being less than 80 dB at one metre (this conforms to E.C. noise regulations).

TMH-20T

The silencer comprises of two type SS, one type F and a further two type SL in this order.

The life expectancy of the silencer correlates closely with the quality of air supplied.

Periodic examination of the silencer is not required, nor is it recommended (see below). As the silencer becomes contaminated a reduced speed of operation will be noted. At this point the nylon silencer should be cleaned or replaced and the gauze silencer should be changed.

4.5 CHANGING THE SILENCER(S) - see parts list.

TMH-20T

Remove the 5 off M5 hex socket cap screws which retain the exhaust plate. Remove the foam silencers. Replace with the new in the correct order. Fit exhaust plate then secure in place with the 5 off hex socket cap screws.



CAUTION

ADJUSTMENTS AND MAINTENANCE OPERATIONS

Before carrying out any work on the hoist the main air supply should be turned off and the residual air vented or the hoist run to dissipate the air pressure.

Red Rooster hoists normally do not require any adjustment as the brake springs take up any wear and the load limiter and limits should not need adjustment once set.

The lubricator should be checked and topped up weekly in normal use or daily when heavily used.

The load chain should be checked monthly for lubrication and oiled if necessary. Where the load chain is not lubricated for operational reasons the chain should be inspected weekly as a dry chain can wear rapidly.

The top and bottom hooks should only be lubricated if required during checks.

The hoist gearbox is greased during assembly or repair and should not need greased during operation.

There are no hazardous substances in Red Rooster hoists.

4.6 CHANGING TROLLEY SILENCERS

Trolleys are fitted with SMC 'AM' type silencers sized to suit the trolley valve. They are easily fitted and removed by a thread end. Silencers should be replaced when damaged or the trolley speed is reduced by contamination.

MAINTENANCE

4.7 FITTING OR REPLACING LOAD CHAIN

The hoist will require to be hung up with an airline connected.

The chain must be fed over the pocket wheel from the slack end anchor side with the weld of every second link facing away from the wheel axis i.e. weld outwards.

Care must be taken not to twist the chain during installation. This is best achieved by holding the live end of the chain as it emerges from the hoist, if the hoist is reeved on two parts of chain, feeding it through the free limit lock, through the bottom block wheel and again as it emerges, thereafter feeding it up to the anchor pin. If the chain cannot be fitted to the anchor without rotating it through 90 degrees, the end link should be removed.

Run the chain through the hoist, leaving a short tail at the 'slack' end. Anchor the slack end without twisting the chain.

Feed the chain over the load wheel.

It is very easy to trap or damage the chain if extreme care is not exercised. Always examine the first link of chain after passing it over the load wheel. If damaged, remove the damaged link(s). **⚠ DANGER**

REPLACING EXISTING CHAIN


Cut away the centre portion of a link of the old chain to allow a chain diameter to pass through. Connect the spare link to the last link of the old chain and the first link of the replacement chain. Use the old chain to draw the replacement chain through the hoist. (Retain the spare link to be re-used). **⚠ DANGER**

FITTING CHAIN TO AN UNCHAINED HOIST

A handy tool comprises a length of either soft insulated wire (about 2mm diameter) or a piece of flexible nylon tube of the same diameter approximately 500mm long. To the end of this attach a similar length of strong twine.

The soft wire or tube is fed over the wheel, its flexibility allows it to follow the chain guide and re-emerge at the opposite side. The twine is attached to the end of the chain and drawn through, pulling the chain against the wheel. By applying power **VERY SLOWLY** in the same direction of winding, the load chain is dragged into the first pocket and over the load wheel. If any resistance is felt as the chain attempts to enter the pocket it is imperative that the chain is released from the pocket before trying again. Otherwise the chain will become trapped and damaged. **⚠ DANGER**

Only use quality load chain approved by Red Rooster for use on our hoists.

⚠ DANGER			
ITEM	CHECK METHOD	CRITERIA	WHEN FAILED
Deformation Flaw Entanglement	- Check visually  - Check visually for no foreign matter as attached sputter.	- No deep notch - No deformation such as twist - No attached sputter - No entanglement - No crack - Wear (see 4.8 + 4.11)	Replace the load chain



HOIST COMPONENTS AND CHAIN

4.8 TYPES OF CHAIN

Only the correct size and grade of load chain should be used. ⚠ **DANGER**
All chain is to EN818/7 - EN1677 standard

TMH-20T	HEAVY DUTY
	RUD RTS
Nominal diameter:	16.0 + 0.1 / - 0.6 mm
Pitch:	45.0 + 0.6 / - 0.3 mm
Max dia at weld:	17.2 mm
Min breaking force:	322 kN
Surface hardness:	ca500-650HV10
Grade:	EN818-7 ISO 3077

NOTE:

When supplied new, only quality chain from a reputable supplier has been fitted to the hoist. Your supplier will be able to offer replacement chain of like quality.

4.9 EMERGENCY LOWERING

In the event of a main air supply failure Red Rooster pneumatic hoists will stop hoisting or lowering and the springs on the disc brake will automatically close the brake holding the load in position.

The next steps will depend on whether the load is being lifted at the time, how long it will be until the air supply is available again and if it is necessary and safe to travel / lower the load to a safe position.

If the problem is a burst hose, this can easily be replaced so there is no need to recover the load, but if the main compressor will not be operational for some time then a suspended load may need to be recovered to a safe position.

OPTIONS:

- 1) A secondary or back up compressor can be used as a temporary supply to move and or lower the load to a safe position.
- 2) Depending on the load and availability of manual rigging gear the load can first be lifted and the air hoist hook disconnected, then the load can be lowered to a safe position.
- 3) An emergency air supply from an air receiver or a high pressure cylinder and regulator set for 6 to 7 Bar pressure can be positioned within the working area of the hoist and the air supply hose connected via an on / off valve which can then be turned on to supply a limited amount of air to make the lift safe. This option will only allow for limited movement so try to choose the option that requires the least amount of running time.

The hoist requires 90 l/sec of air to lower a load so it can quickly use up a volume of compressed air.


If it is decided the safest course of action is to keep the hoist suspended the load then slings and shackles should be used to connect to the load from above (with a SWL equal or greater than the load being lifted by the hoist), to hold the load in case of brake slippage over a long period.



HOIST COMPONENTS AND CHAIN

4.10 TMH-20T


CHAIN FITTINGS



1	Load Sheave
2	Idle Sheave
3	Live End Chain Anchor
4	Dead End Chain Anchor
5	Welding Area
6	Limit Lever

TMH-20T

HOIST PARTS









1	Upper Hook
2	Hook Safety Latch
3	Silencer Section
4	Motor Section
5	Brake Section
6	Load Limiter
7	Valve Section
8	Pendant Hose Set
9	Pendant Control with E/Stop
10	Lower Hook
11	Gear Box
12	Hanger Eye for Lifting the Hoist
13	Chain
14	Limit Lever Lowering
15	Limit Lever Lifting
16	Cord Control Lowering
17	Cord Control Lifting



SERVICE DATA







Maintenance chart
TMH-20T

NO.	DESCRIPTION	CHECK POINTS	STD DIMENSIONS & MAX FOR REPLACEMENT
55	Vane		STD L = 136mm MIN L = 135mm STD W = 23mm MIN W = 21mm STD T = 4mm MIN T = 3.5mm Replace if any of the width, length and thickness is less than the stated minimums.
152	Brake Disc		STD T = 8mm MIN T = 7.3mm Below minimum for replacement. STD W = 2.6mm MAX W = 2.8mm Above maximum for replacement
213	Cage		Replace when there is a large or uneven play in the pin hole.
201 202 204 205 206 208 209 210 212	First pinion First star gear First ring gear Second pinion Second star gear Second ring gear Third pinion Third star gear Third ring gear		Replace if there is a step on the surface of the gear teeth.
203 207 211	First pin Second pin Third pin		Replace if there is a step on the surface of the pin. If the pin is replaced, replace the needle bearing and star gear at the same time.
128	Chain end pin		Measure the contact area of the pin and the chain. Replace if the wear exceeds 1mm.



SERVICE DATA




Maintenance chart
TMH-20T

NO.	DESCRIPTION	CHECK POINTS	STD DIMENSIONS & MAX FOR REPLACEMENT
113	Wheel		Replace if load-sheave part is badly damaged or worn.
111	Chain Guide		Replace if the wear of any part of the chain guide exceeds more than 1mm. Replace when it has cracks or critical damage caused by chain.
116	Chain Separator		STD L = 40mm MAX L = 42.8mm STD W = 60mm MAX W = 63mm Replace if any of the above dimensions exceed maximum wear. Replace when it cracks or critical damage
250	Hook		Dimensions: STD L = 60.0mm MAX L = 61.2mm STD H = 62.0mm MIN H = 59.5mm Check dimensions as casting size can vary. Replace if beyond maximum 'L' or minimum 'H'. There is some variation in the 'H' size on hooks so it is best to measure the hook when new and then allow up to 1mm of wear.
143	Load Chain		STD L = 225mm MAX L = 228.5mm Replace if L exceeds MAX L. STD D = 16mm MIN D = 15.5mm Replace if D exceeds MIN D Also replace if the link chain is severely damaged.
			Measure the chain diameter (d) with point caliper.



SERVICE DATA

Maintenance chart
TMH-20T

NO.	DESCRIPTION	CHECK POINTS	STD DIMENSIONS & MAX FOR REPLACEMENT
201	First pinion		STD W = 1.75mm MIN W = 1.5mm Below minimum for replacement
53	Rotor		STD W = 1.75mm MIN W = 1.5mm Below minimum for replacement.
115	Coupling		STD W = 2.6mm MAX W = 2.8mm Above maximum for replacement.



LAYING UP THE HOIST

5.1 LAYING UP THE HOIST

Whenever the hoist is unused for a period (weekends, holidays or in store), a little preparation will ensure that the hoist operates correctly and safely, either before being put into service for the first time or when being put back into service after a layup.

SHORT LAY UP PERIOD (2 TO 90 DAYS):

Air hoists should be kept clean, lubricated and stored in a clean and dry location.

When not in use seal off from the air supply inlet and run extra oil through the hoist as per lay up instructions.

Wherever possible keep the hoist protected when in use and installed in an exposed location, protecting controls and hoses from damage.

Turn up the oil delivery rate of the lubricator to maximum and run the hoist for two minutes, thereby ensuring that the hoist motor and control valve are well lubricated. (This also helps to displace any water which may be lying in the hoist). ⚠ **CAUTION**

LONG TERM LAY UP PERIOD (3 MONTHS TO 12 MONTHS):

- Heavily lubricate the hoist as specified above.
- If the hoist is contaminated with dirt or chemicals, wash with a propriety mild solvent or detergent and thoroughly rinse off with fresh water. Allow to dry and spray lightly with penetrating fluid.
- Lubricate the load chain, limit shafts, safety latches, and hook swivels.
- Disconnect the air supply and plug the inlet port.
- If required, dismantle the chain collector, pendant, air set and trolley for storage.
- Store in a dry ventilated area.
- Secure hoist in a crate or suitable pallet.

Transportation - Moving your Red Rooster hoist between locations.

Carefully disconnect from suspension point and lower under control to ground level.

Be sure that chain collector, valves and trolley drives are not damaged.

Carefully lay the pendant on top of the hoist making sure tubes or hoses are not damaged.

Secure the hoist and chain to the shipping container or pallet.

For long term storage corrosion inhibitors (wax coatings) can also be applied to suitable surfaces and then removed before use.

Before connecting the air supply line to the hoist, pour 5 to 10 cc of Atlub air tool oil directly into the airline to ensure that oil is present in the motor startup. ⚠ **CAUTION**

If being stored long term especially outside ask for a copy of the full procedure - AHLU-15

CHAIN COLLECTORS

- 6.1 When supplied new the chain bucket will have been sized to suit the HOL of the hoist with spare capacity to allow for some bunching up of the chain. The use of a chain collector can make the operation of the hoist more efficient preventing dangerous occurrences with the chain getting caught or falling from the load being lifted as it mounts up on top of the load.


Galvanised chain collectors are used as standard, with stainless steel buckets being used on UK Ex / ATEX hoists and in areas of high corrosion.

On arrival at site the load chain should be removed from the chain collector either manually or by carefully running out of the hoist checking for snagging. The chain should then be run back into the collector by the hoist checking there are no twists in the chain that the bottom hook is not twisted through the chain fall on multi-fall blocks.

Hoists with long drops of chain and heavy loads in the chain collectors will require a secondary suspension point to hold the hoist in a vertical position when unloaded. These may be as shown in section 1.8 or a secondary trolley on a runway beam.

If operating without a chain collector the slack end of the chain may catch or get caught on top of a load. Always make sure the unloaded chain is running freely.

- Do not exceed the chain collector capacity.
- When the load chain is dry it may not run freely into the chain collector and over fill the collector, so the chain must be kept lubricated to prevent it running out of the collector.
- Make sure the chain collector brackets have not been damaged during installation.
- Make sure the chain collector is free to move when the hoist is loaded and un-loaded.
- Make sure the bottom hook does not connect with the chain collector. Limit the lifting height of the bottom hook if necessary.
- For any assistance required on chain collectors please contact Red Rooster Lifting Ltd.



TMH	
1	Bucket Bracket RRL 1594-04
2	Chain Bucket
3	Dead End Support Pin RRL 1591-55
4	Qty 2 - Split Pin 4x32




SPEED & LOAD LIMITER ADJUSTMENT

7.1 SPEED ADJUSTMENT

Every TMH hoist is checked at the factory to ensure the maximum hoisting speed is in accordance with the specification.

CORD CONTROL HOIST

The speed of the hoist is proportional to the amount of downward movement in the control cord, which via the cord lever controls the amount by which the valve is opened.



MAXIMUM LOAD ADJUSTMENT

On every TMH hoist the load limiter is factory set to operate at a load ten percent in excess of the safe working load, at an operating pressure of 6 bar. Unless a lower supply pressure is to be used, the load limiter will not require adjustment.


All models in the range incorporate an adjustable load limiter.

HOW IT WORKS

Located adjacent to the control valve, the load limiter measures the pressure drop across the motor which is proportional to the load on the motor. Once the pressure drop is increased above that of the load limiter setting, the brake is applied and the hoist will not lift the load. In this case the load should then be reduced or a larger capacity hoist installed. The load can still be lowered when the load limiter cuts in.

7.2 SETTING THE LOAD LIMITER

Viewing the hoist from the motor end, the load limiter adjusting screw (M6 hex) is located on the left hand side on the valve cover. It is locked in position with an M6 nut. Back off the lock nut before commencing adjustment.



- Set the regulator pressure to that which will be used during operation (normally 6 bar to 90 p.s.i.).
- Turn the adjustment screw anti-clockwise until no resistance is felt and then turn clockwise until the internal spring starts to resist.
- Apply the safe working load in the hoisting mode slowly and then at full speed. The hoist will stop automatically.
- Rotate the screw one turn in a clockwise direction and again engage the hoisting mode.
- Continue, one rotation at a time until the load limiter fails to stop the hoist.
- Turn the screw 1/4 turn clockwise and ensure the load limiter is operating at this point. (If not continue in a clockwise direction a fraction of a turn at a time until the load limiter operates.
- Fasten the lock nut to secure the adjustment screw.
- The load limiter is now set. A significant change in the operating pressure from that selected will necessitate adjustment of the load limiter.
- The maximum travel of the adjustment screw is approximately eight turns, If adjusted to this point, the load limiter will not operate. **⚠ CAUTION**

OPERATIONAL BREAKDOWN / TROUBLESHOOTING THE TMH HOIST

8.1 We list below a number of faults which may occur during use, together with the probable cause and the cure. If you experience a fault and cannot identify the cause, or if you do not feel confident to remedy the fault, please revert to your hoist supplier.

Description of fault noted	Possible cause of fault	Remedy
Does not operate (Valve does not work)	Lack of air pressure Damage of Pendant hose Foreign material is stuck in pendant or piping part Rust of valve part Limit shaft is stuck by rust Over tightening assembly bolts of valve body Damage of O-ring in Valve part	Adjust air inlet pressure (6 Bar) Replace pendant hose Remove the foreign material Replace the defect part Replace Limit shaft, Limit shaft bush Re-tighten bolts with right torque Replace damaged O-ring
Does not operate (Valve works)	Lack of air pressure Incorrect assemble of Valve bush Defective part in Motor Defective part in Gear Brake is not released due to damage on O-rings and packing	Adjust air inlet pressure (6 Bar) Reassemble Valve bush Replace part Replace part Replace defective O-ring, gasket
Lifting and lowering speed is slow	Lack of air pressure Hose is too long, or size is small. Or air pressure loss due to using quick coupler Foreign material is stuck in pendant or piping part Incorrect assemble of Valve bush Damage on Pendant hose Lack of Oil Silencer parts are clogged Defective parts in Motor Defective parts in Gear Brake is not released due to damage on O-rings and packing Air pressure for Valve releasing is not enough due to using long pendant hose	Adjust air inlet pressure (6 Bar) Adjust hose length, or change hose and piping part Remove foreign material Reassemble Valve bush Replace Pendant hose Adjust quantity of oil Clean each silencer or replace Replace defect part Replace defect part Replace defective O-rings and packing Adjust the set up for long pendant hose
Operation does not stop despite releasing pendant lever or cord	Over tightening of valve body assembly bolts Limit shaft function is disturbed due to rust etc. Damage on O-ring in Valve part	Re-tighten bolt Replace Limit shaft, Limit shaft bush Replace defective O-ring



OPERATIONAL BREAKDOWN / TROUBLESHOOTING THE TMH HOIST

8.1 Continued

Description of fault noted	Possible cause of fault	Remedy
Cannot lift or lower rated load	Lack of air pressure Hose is too long, or size is too small. Or air pressure loss due to using quick coupler Damage on Pendant hose Foreign material is stuck in pendant or piping part Defective operation caused by rust of Valve part Limit shaft does not move smoothly due to rust Incorrect assembling of Valve bush Adjustment of Load Limiter is not correct Silencer parts are clogged Defective parts in Motor Defective parts in Gear Brake is not released due to damage on O-rings and packing	Adjust air inlet pressure (6 Bar) Adjust hose length, or change hose dia and piping part Replace hose Remove foreign material Replace defective part Replace Limit shaft and Limit shaft bush Reassemble Valve bush Adjust Load limiter as per section 7.2 Clear each Silencer or Replace Replace defective part Replace defective part Replace O-ring and Gasket
Cannot perform slow speed operation or not continue	Damage on O-ring in Valve part Limit shaft function is disturbed due to rust etc. Defective Lift spring in Motor part Over tightening of adjust screw of pilot air Defective bearing on Limit lever Defective parts in Motor part	Replace defective O-ring Replace Limit shaft, Limit shaft bush Replace Lift spring Adjust the set up for long pendant hose Replace Bearing Replace defective part



PERIODIC EXAMINATION AND TESTING

9.1 EXAMINATION

UK & European Law requires that a thorough examination of the hoist should be carried out by a competent person:

- Before being put into service.
- At a frequency not exceeding 12 months (6 months for equipment used offshore).
- After being put into service at a new site.
- After involvement in an accident or dangerous occurrence.
- After a significant change in the conditions of use.
- After long periods out of use (time not specified).

Lifting operations and lifting equipment regulations 1998, section 9 refers. (LOLER 1998 №2307)

The record of such examination must be retained for as long as the employer continues to operate the equipment. The regulations also call upon the employer to carry out a risk assessment; to adjust the frequency of inspection according to the potential risk, to determine the nature of inspections and to ensure that the persons carrying out the inspection are competent to do so.

9.2 SIX MONTHLY OFFSHORE INSPECTION

Arrange to have the hoist examined by a person specifically trained and experienced in the examination of lifting machines. This can be done by a Red Rooster engineer or an independent competent person. Ensure that the party is operating to a detailed inspection procedure or code of practice.

SERVICE

We would recommend the hoist is returned every 5 years for a full inspection and service.

9.3 TESTING

LOLER 98, section 4 calls for the employer to ensure that the hoist is of adequate strength and stability for each load. No frequencies or test or proof loads are specified.

In the case of the TMH hoists the hoist is functionally tested with a proof load of 125% of the safe working load prior to delivery (Test certificate refers).

It is recommended that the test is repeated along with a thorough examination if the hoist is substantially repaired (i.e. any repair which may affect the hoists ability to lift, lower and sustain a load).

REPEAT PROOF LOAD TESTING OF THE HOIST SHOULD BE AVOIDED

NOTE!

If your hoist is a "spark resistant" zone 1 version; check the bronze coating of the lower and upper hook on signs of wear. A worn out coating is NOT spark resistant anymore and can cause dangerous situations. Therefore let the bronze coating be renewed by your supplier in time.

DUTY RATINGS

10.1 FEM 9.511 classifies the theoretical loading conditions and operating time in hours per day.

FEM 9.755 classifies the theoretical duration of service for safe operation.

APPLICATION OF FEM RULES TO PNEUMATIC HOISTS

With most mechanical equipment, the limiting factor with regard to operating time is that of HEAT GENERATION.

For example, an electric motor if not periodically allowed a 'rest period' to allow it to cool down after each period of use will cease to function due to irreversible damage arising as a consequence of the heat.

Air motors perform differently. Although heat is generated, providing that the motor is properly lubricated, no damage will ensue. The expanding air at the outlet manifold also has a cooling effect on the motor.

As a result pneumatic motors are commonly referred to as 100% duty rated or continuous rated, which means simply that they may be used continuously without a cooling down period and without damage arising as a consequence.

Incorporated into the TMH hoist are three classes of components:

1. Sacrificial components - These components are designed to incur wear to either protect other components or to function by means of friction generation. They require periodic inspection and replacement and comprise of the rotor vanes and the brake disc. Inadequate lubrication seriously reduces the life expectancy of the vanes.
2. Load chain - Whilst adequate lubrication of the load chain will reduce friction and thereby limit the wear occurring between the bearing points of adjacent links, it will not totally eliminate it. Hence it will require regular inspection and will also require replacement within the service life of the hoist.
3. Structural and mechanical components - These comprise all other parts of the hoist, including gearbox and bearings, rotor and housing, valve, hooks, pins etc. A theoretical service life for every component has been calculated (available on request). For the purposes of the summary, the SHORTEST service life of any component has been included.

10.2 TABLES OF DUTIES - TMH-15T & TMH-20T Hoist

FEM standard	For all mentioned T models
FEM 9.511	1 Bm (M3)
Theoretical duration of service	
FEM 9.755	
Sacrificial components	1 Bm (M3)
Load chain	2M (M5)
Structural & mechanical components*	1Am (M4)

*Shortest duration stated.

IMPORTANT NOTES

- ▷ A hoist is deemed to be operating when it is in motion.
- ▷ All ratings are based on a clean, dry, air supply and correct lubrication.
- ▷ Load chain must be to manufacturer's specification.
- ▷ Special chains are excluded (consult your supplier).
- ▷ Mode of use must be in accordance with manufacturer's recommendation.

EXPLOSION PROTECTION

- 11.1 The UK is now covered by the UK Ex scheme for the use of non-electrical in hazardous areas and is covered by the 'Product Intended for use in Potentially Explosive Atmospheres Regulation 2016' (UK SI 2016: No 1107 as amended by UK SI 2019 No 696 Schedule 25, schedule 3A, Part 6)

For Europe and many other parts of the world we also offer ATEX Non-electrical equipment certified under the ATEX 2014/34/EU Directive.

For both the UK Ex and ATEX this is split into two categories of equipment available from Red Rooster – Group – I mining (I M2 De-energised in an emergency) and group II – Zone 1 + 21 & Zones 2 + 22)

The Explosive Protection Level (EPL) has been set when the effective ignition sources are identified and when they become effective in normal operation and in the case of expected malfunctions. The normal ambient temperature range for Red Rooster air hoists is -20°C to +60°C.

As standard all Red Rooster air hoists are certified as Group II Category 3 (Zone 2 Gas or 22 Dust)
This excludes the TMM-140 & TCR-250 ME. (standard only)

Standard hoists are suitable for use in ZONE 2 Gas areas certified as Ex Group II 3 G Ex h IIB T4 Gc
Standard hoists are suitable for use in ZONE 22 Dust areas certified as Ex Group II 3 D Ex h IIIB T135°C Dc

With extra protection can be used in ZONE 1 Gas areas certified as Ex Group II 2 G Ex h IIB T4 Gb
With extra protection can be used in ZONE 21 Dust areas certified as Ex Group II 2 D Ex h IIIB T135°C Db

Further protection allows the hoist to work in ZONE 1 Gas areas certified as Ex Group II 2 G Ex h IIC T4 Gb
Further protection allows the hoist to work in ZONE 21 Dust areas certified as Ex Group II 2 D Ex h IIIC T135°C Db
(not suitable for TCR Mini or TCS range, IIC or IIIC areas)

Red Rooster hoists will cover temperature classes T1 to T4 so can be certified to work with all Gases with the exception of Carbon Disulphide which is in temperature class T6.

The glow temperatures for dusts must be above 220°C or ignition temperatures above 202°C for use in Zones 21 and 22.

Mining – Ex Group I M2 Ex h I Mb (Mechanical equipment de-energised in an emergency)

TROLLEYS AND OVERHEAD CRANES

Red Rooster trolleys and overhead cranes use standard steel wheels for use in a Zone 2 + 22 area and normally with Bronze wheels in a Zone 1 + 21 area with a Gas group of IIB or IIC and Dust group IIIB or IIIC. The normal running speeds of our trolleys and overhead cranes are less than the 1 m/s that the standard allows. (Steel wheels can be acceptable for Zone 1 Gas Group IIB / Dust Group IIIB)

When built into an assembly such as an overhead crane the UK Ex / ATEX rating will be for the complete assembly, which may be less than some of the individual parts.

SPECIAL INSTRUCTIONS

This section of the manual refers to special instructions, exclusions or warnings about the equipment.

LUBRICATION

Lubrication oil should not have an ignition temperature below T135°C (T4) BS EN80079-36:2016.

Several gases such as hydrogen sulphide and ethylene oxide are at the very top of the IIB temperature class and are extremely flammable so you may wish to include them in the higher IIC temperature class. This is also relevant for impact sensitive dusts, around light metals, dusts with glow temperatures less than 210°C and ignition temperatures below 202°C. In an area where combustible dusts are present the surface temperature cannot exceed two thirds of the minimum ignition temperature of the dust and air mixture or the glow temperature of the dust.

Ambient temperature range for air hoists and air trolleys is -20°C ≤ Ta ≤ +60°C

Some models of Red Rooster equipment can only be certified for use in temperature class T5 or T6 when a special assessment has been completed.

Air motors, control valves and hoses are all positively pressurised so gas or dust cannot penetrate internal parts when operating or when under pressure.

Red Rooster hoists and trolleys are constructed to avoid the build-up of dust deposits. But where dust does build up, provision shall be made for removal of the dust and keeping the hoist, trolley and pipework clean.

External influences such as heat from direct sunlight or exhausts can affect the hoist so the ambient temperature should be checked. Other influences such as cold, wind, water, compressor air temperature, contact with chemicals and mechanical hazards can all have an effect on the hoist operation.

EXPLOSION PROTECTION

11.1 EARTHING

The hoist or hoist and trolley should normally earth through the top hook or the running wheels of the trolley into the supporting steel structure. If this does not happen then the hoist can earth through the load chain of the hoist, when grounded. If the chain is rusty it can affect the earthing of the hoist. During inspection the chain may need cleaning, oiling or replaced to allow adequate earth leakage. If the earth leakage is less than that recommended a separate earth strap should be fitted. Neither the running surface of beams nor the wheels should be painted. During lifts the load may be required to be earthed if there is any doubt as to the earth leakage from the hoist.

IMPACT HAZARDS

The materials chosen and their coverings should help to prevent an ignition hazard so that a corroded section of steel does not impact against a light metal or high grade steel. The selected materials and the design should exclude as far as possible mechanical sparks due to impact, sliding or friction. Where external housings are made of aluminium then the possibility of impact should not be possible.

PLASTIC SURFACES

Where plastic has been used for the pendant, control boxes or on the hoist these surfaces must only be cleaned with a damp cloth (water), which reduces electrostatic charging due to friction from wiping with a cloth.

COMPRESSED AIR HOSES

All air hoses used in a Zone 1 + 21 & 2 + 22 areas should be 'Anti-Static' with a sufficiently low surface resistance to prevent an electrostatic ignition hazard. The Hose should always have a higher Safe Working Pressure than the hoist and above that of the air supply from the compressor.

Air supply hoses need to be certified with a current report on the condition of the hose and checked before fitting to the hoist. The burst of a hose or connection failure can create a dust cloud and also create a static charge.

Hose safety whip cables should be used to prevent hoses flying if a connection fails to limit the dust cloud and the flying hose.

*Red Rooster hoists should only be operated with compressed air.

MINING APPLICATIONS

In general most standard Red Rooster hoists can be used for underground mining operations along with the surface buildings and services. The equipment is certified for Group I M2 use, so must be switched off / isolated in the event of an emergency. The equipment has to be robust, non-sparking, taking into account the conditions and the handling underground and be built to survive along with explosive protection from Methane gas / dust - Firedamp. The maximum surface temperature of 150°C for coal dust atmospheres will not be reached where a coal dust layer can be formed or 450°C where coal dust will not form a layer.

For mining hoists the lubrication oil shall be replaced with non-flammable substances or substances not capable of forming explosive atmospheres (BS EN 1127-2:2014). Hoist lubrication is controlled by the drip setting on the lubricator and set as per the manual.



DANGER

- During use the operator must avoid loads or the bottom hook impacting with surrounding steel equipment and structural steel which may result in sparking or frictional sparks caused by dragging loads past fixed structures.
- Any impacts involving light metal or cast iron should be avoided and these materials either protected or removed from the area.
- Damaged or badly corroded coatings or chain should be replaced or repaired to keep up the UK Ex / ATEX rating of the equipment. For assistance contact RRL.
- Earthing of hoists is not usually required as the hook connection to structure allows the hoist to connect to earth.
- The running surfaces of beams and cranes should not be painted to allow wheels to earth to the structure.
- Stainless steel 'C' track systems should be applied with an earth wire to connect onto the structure.
- Plastic junction boxes should only be cleaned with water and a clean cloth to reduce any electrostatic charge coming from the rubbing of the plastic surface.
- Dust should not be allowed to accumulate on the hoist, trolley, crane or junction boxes.
- Only use a damp cloth for wiping plastic surfaces.

TECHNICAL SPECIFICATION - STANDARD 4 WHEEL TROLLEYS

12.1 TABLE 1

Lubricator recommended drop rate per minute

TROLLEY CAPACITY	CONTINUOUS OPERATION	INTERMITTENT OPERATION
9 to 25 Tonne	5 - 6	10 - 12

TABLE 2

Beam trolley flange ranges for four wheel trolleys

FLANGE WIDTH RANGE	LIFTING CAPACITY (TONNES)		
	10 Tonne	15 Tonne	20 Tonne
R1	110 to 180 mm	110 to 180 mm	130 to 200 mm
R2	180 to 240 mm	180 to 240 mm	200 to 260 mm
R3	240 to 300 mm	240 to 300 mm	260 to 320 mm

TABLE 3

LIFTING CAPACITY	TROLLEY SPEEDS			AIR CONSUMPTION
	STANDARD	OPTION	UK Ex / ATEX	
9 to 12 Tonne	8 m/min	N/A	N/A	50 l/sec at 6 Bar
15 Tonne	6 m/min	N/A	N/A	50 l/sec at 6 Bar
20 to 25 Tonne	4 m/min	N/A	N/A	50 l/sec at 6 Bar

TABLE 4

LIFTING CAPACITY	MINIMUM BEND RADIUS
3 to 12 Tonne	2.5 m
15 to 25 Tonne	3.0 m


TMH-20T-LHR LOW HEADROOM AIR HOIST



**RED ROOSTER
LIFTING**

RAISING EXPECTATIONS

The **TMH-20T-LHR** is a 20 tonne low headroom chain hoist and trolley from Red Rooster Lifting. This is part of our air hoist and trolley range for lifting equipment applications in industry.



The new **Red Rooster Lifting** TMH series air hoist and trolleys have the highest lifting speed with the lowest headroom on the hoist market. The TMH hoists are designed to operate at full lifting capacity with an air pressure from 4 – 6.3 bar. For full speed operation the hoist air pressure should be 6.3 bar.

STANDARD FEATURES

- Toku rotary vane motor
- Robust 3 step planetary gearbox
- Failsafe automatic internal disc brake
- Upper & lower limit switches
- Cast steel housing
- Internal silencing down to 80 dB(A)
- Alloy safety swivel hooks with safety catch
- Load chain of European manufacture EN818-7
- Automatic load limiter

AVAILABLE OPTIONS

- Marine specification
- Collision bumpers
- UK Ex scheme or ATEX zone 1 specification
- Articulated trolleys
- Rack & pinion drive
- Travel limits
- Air Service units
- Festoon systems
- Radio control remote
- Main air shut off valve
- Special paint systems
- Beam brake
- Other travel speeds



**UK EX SCHEME ZONE 2
ATEX ZONE 2
AS STANDARD**

T: +44 (0) 1651 872101
sales@redroosterlifting.com

REDROOSTERLIFTING.COM

Red Rooster Lifting Limited Nauta House, The Meadows, Oldmeldrum, Inverurie, Aberdeenshire, UK, AB51 0EZ

TMH-20T-LHR LOW HEADROOM AIR HOIST



**RED ROOSTER
LIFTING**



RAISING EXPECTATIONS

DIMENSIONS

All measurements are in mm
Information subject to change without notice

MODEL	TMH-20T-LHR
WLL	20000 kg
CHAIN FALLS	4
LIFTING SPEED FULL LOAD (M/MIN)	0.8 m/min
LIFTING SPEED WITHOUT FULL LOAD	1.6 m/min
LOWERING SPEED FULL LOAD	1.6 m/min
TRAVEL SPEED	6.8 m/min
HOIST AIR CONSUMPTION	58 l/sec
TROLLEY AIR CONSUMPTION	40 l/sec
INLET CONNECTION	1" BSP
WEIGHT WITH 3M HOL	950 kg
ADDITIONAL METRE HOL	22.8 kg
FLANGE MINIMUM	130 mm
FLANGE MAXIMUM	300 mm
G.A. DRAWING	RRL 1597-00

-LHR = STANDARD -LHR-ATX = ATEX



T: +44 (0) 1651 872101
sales@redroosterlifting.com


REDROOSTERLIFTING.COM

Red Rooster Lifting Limited Nauta House, The Meadows, Oldmeldrum, Inverurie, Aberdeenshire, UK, AB51 0EZ





DRAWINGS AND PARTS LISTS

REVISION HISTORY		
REV.	DATE	APPROVED
0	09/08/2024	PAUL SHEWMAN



SCALE		MATERIAL		TITLE OF PART		GENERAL ASSEMBLY		PART NUMBER	
NTS		(OR EQUIVALENT)		SIGNATURE		DATE		RRL 1597-00 1 / 2	
DESIGNED BY		T. MIKOLAJEWSKI		18/06/2024		18/06/2024		ALL DIMENSIONS ARE IN MILLIMETERS TOLERANCES UP TO 5 ±0.05 OVER 5 UP TO 10 ±0.1 OVER 10 UP TO 20 ±0.2 OVER 20 UP TO 50 ±0.5 OVER 50 ±1.0 OVER 100 ±1.5	
DRAWN BY		T. MIKOLAJEWSKI		18/06/2024		REVISION WEIGHT		0 ~950KG	
CHECKED BY		P. SHEWMAN		27/06/2024		REPLACES DRAWING		-	
APPROVED BY		P. SHEWMAN		28/06/2024		PROFILE NUMBER		-	
SHEET SIZE		A3		TITLE OF PROJECT		TMH20 - 20T 4F LHR		SURFACE ROUGHNESS R_a IF IN DOUBT ASK	


REVISION HISTORY		
REV.	DATE	APPROVED
0	09/08/2024	PAUL SHEWAN




20T 4F LHR Trolley STANDARD VERSION - PARTS LIST				
ITEM	QTY	PART NUMBER	DESCRIPTION	REV.
1	1	RRL 1597-19	LOAD BAR	0
2	1	RRL 1597-20	LOAD BAR	0
3	1	RRL 1597-04	MOTOR PLATE W	0
4	1	RRL 1597-05	SIDE PLATE W	0
5	2	RRL 1505-1ST	PLAIN WHEEL - STANDARD VERSION	0
6	2	DIN 625 SKF - SKF 6317-2Z	DEEP GROOVE BALL BEARINGS SINGLE ROW WITH TWO Z SHIELDS SKF	0
7	2	DIN 472 - 180 X 4	SPRING RETAINING RING	0
8	2	DIN 471 - 65X3	RETAINING RINGS FOR SHAFT	0
9	2	RRL 1504-1ST	GEAR WHEEL - STANDARD VERSION	0
10	2	DIN 625 SKF - SKF 6313-2Z	DEEP GROOVE BALL BEARINGS SINGLE ROW WITH TWO Z SHIELDS SKF	0
11	2	DIN 472 - 140X4	RETAINING RINGS FOR SHAFT	0
12	2	DIN 471 - 65X2,5	RETAINING RINGS FOR SHAFT	0
13	2	1600812Z	SINGLE ROW BALL BEARINGS WITH TWO METAL SHIELDS	0
14	12	ISO 10642 - M8 X 30	HEXAGON SOCKET CONTINUOUS HEAD SCREW	0
15	2	DIN 472 - 68 X 2,5	RETAINING RINGS FOR SHAFT	0
16	2	DIN 471 - 40X1,75	RETAINING RINGS FOR SHAFT	0
17	1	DIN 6885 - A 8 X 7 X 4,5	PARALLEL KEY	0
18	2	DIN 6885 - A 8 X 7 X 90	PARALLEL KEY	0
19	1	DIN 913 - M5 X 8	HEXAGON SOCKET SET SCREW	0
20	2	DIN 128-1 - A 62	WASHER	0
21	4	ISO 4032 - M6	HEX NUT. PRODUCT GRADES A AND B	0
22	2	CSN EN 151234-8x70	SPLIT PIN	0
23	2	ISO 128-1 - A 50	WASHER	0
24	2	ISO 1335 - A 50	WASHER	0
25	2	DIN EN ISO 1234-3x62	HEX NUT. PRODUCT GRADES A AND B	0
26	2	RRL 1504-11ST	ANTI TIP ROLLER STANDARD VERSION	0
27	8	NL 24SP	SPLIT PIN	0
28	2	RRL 1597-25	M24 NORDLOCK WASHER LARGE DIAMETER GLUED PAIR	0
29	8	ISO 4032 - M24	HEX NUT. PRODUCT GRADES A AND B	0
30	2	RRL 1597-26	TRANSFER GEARWHEEL	0
31	1	SK(S)63FH-IEC80-50H	GEARBOX	0
32	4	DIN 913 - M10 X 40	HEXAGON SOCKET SET SCREW	0
33	4	NL 10	M10 NORDLOCK WASHER GLUED PAIR	0
34	16	ISO 4032 - M10	HEX NUT. PRODUCT GRADES A AND B	0
35	1	DIN 471 - 25X1,2	RETAINING RINGS FOR SHAFT	0
36	1	VSOCYXX00	AIR MOTOR	0
37	4	DIN 931-1 - M10 X 40	HEX-HEAD BOLT	0
38	4	DIN 7980 - 10	SPRING WASHER	0
39	1	RRL 1597-27	TRANSFER SHAFT	0
40	12	NL 10SP	M10 NORDLOCK WASHER LARGE DIAMETER GLUED PAIR	0
41	1	RRL 1505-17	BRACKET PLATE	0
42	1	RRL 1597-CV	CONTROL VALVE C/W FITTINGS	0
43	3	NL 8	M8 NORDLOCK WASHER GLUED PAIR	0
44	3	ISO 4762 - M8 X 25	HEXAGON SOCKET HEAD CAP SCREW	0
45	3	NL 8SP	HEX NUT. PRODUCT GRADES A AND B	0
46	3	ISO 4032 - M8	HEX NUT. PRODUCT GRADES A AND B	0
47	2	RRL 1597-28	TIE ROD	0
48	1	RRL 1597-29	FINION SHAFT	0
49	4	RRL 1597-30	BRACKET ROD	0
50	8	DS1789	1 3-8" BLACK RUBBER STOP	0
51	8	DIN 125 - A 6,4	WASHER	0
52	8	ISO 4032 - M6	HEX NUT. PRODUCT GRADES A AND B	0
53	8	DIN 912 - M6 X 50	CYLINDER HEAD CAP SCREW	0
54	6	RRL 1597-38	SPACER	0
55	6	RRL 1504-10	SPACER WASHER	0
56	5	RRL 1503-09	SPACER	0
57	5	RRL 1503-10	SPACER WASHER	0

SCALE		MATERIAL		TITLE OF PART		TROLLEY		PART NUMBER	
NTS		(OR EQUIVALENT)						RRL 1597-01 1 / 4	
DESIGNED BY		DATE		DATE		REVISION WEIGHT		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN MILLIMETERS TOLERANCES LINEAR UP TO 5 4/100 OVER 5 UP TO 30 5/100 OVER 30 UP TO 100 6/100 OVER 100 0,15 ANGULAR ±0,5° SURFACE ROUGHNESS √ IF IN DOUBT ASK	
DRAWN BY		19/06/2024		19/06/2024		0 352,8 KG			
CHECKED BY		27/06/2024		27/06/2024		REPLACES DRAWING			
APPROVED BY		28/06/2024		28/06/2024					
SHEET SIZE		TITLE OF PROJECT		TMH20 - 20T 4F LHR		PROFILE NUMBER			
A3									

20T 4F LHR TROLLEY - STANDARD VERSION


[illegible]



20T 4F LHR Trolley ATEX VERSION - PARTS LIST			
ITEM QTY	PART NUMBER	DESCRIPTION	REV.
1	RRL 1597-19	LOAD BAR	0
2	RRL 1597-20	LOAD BAR	0
3	RRL 1597-04	MOTOR PLATE W	0
4	RRL 1597-06	SIDE PLATE W	0
2	DIN 625 SKF - SKF 6317-2Z	DEEP GROOVE BALL BEARINGS SINGLE ROW WITH TWO Z SHIELDS SKF	0
9	DIN 472 - 180 x 4	SPRING RETAINING RING	0
2	DIN 471 - 85X3	RETAINING RINGS FOR SHAFT	0
8	DIN 625 SKF - SKF 6313-2Z	DEEP GROOVE BALL BEARINGS SINGLE ROW WITH TWO Z SHIELDS SKF	0
10	DIN 472 - 160x4	SPRING RETAINING RING	0
2	DIN 471 - 65X2,5	RETAINING RINGS FOR SHAFT	0
12	ISO 1000842 - 148 x 30	SINGLE ROW BALL BEARINGS WITH TWO METAL SHIELDS	0
14	DIN 472 - 65 X 2,5	HEXAGON SOCKET CONTENSION HEAD SCREW	0
16	DIN 471 - 65 X 1,2	SPRING RETAINING RING	0
17	DIN 472 - 65 X 1,2	RETAINING RINGS FOR SHAFT	0
18	DIN 4985 - A 8 x 7 x 4,5	PARALLEL KEY	0
19	DIN 913 - M5 x 8	PARALLEL KEY	0
20	DIN 125-2 - A 4,9	HEXAGON SOCKET SET SCREW	0
21	ISO 4035 - M5,6	WASHER	0
22	CSN EN ISO 1234 - 8x70	HEX NUT. PRODUCT GRADES A AND B	0
23	DIN 125 - A 50	HEX NUT. PRODUCT GRADES A AND B	0
24	ISO 4035 - M4,8	WASHER	0
25	DIN EN ISO 1234 - 6.3x62	HEX NUT. PRODUCT GRADES A AND B	0
27	RRL 1597-25	M24 NORDLOCK WASHER LARGE DIAMETER GLUED PAIR	0
28	ISO 4032 - M24	BEARING HOLDER	0
29	RRL 1597-26	HEX NUT. PRODUCT GRADES A AND B	0
30	SKS163FH-IC80-50.1	TRANSFER GEARWHEEL	0
31	DIN 913 - M10 x 40	GEARBOX	0
32	NL 10	HEXAGON SOCKET SET SCREW	0
33	ISO 4032 - M10	M10 NORDLOCK WASHER GLUED PAIR	0
34	DIN 471 - 25x1,2	HEX NUT. PRODUCT GRADES A AND B	0
35	ISO 4032 - M10	RETAINING RINGS FOR SHAFT	0
36	ISO 4032 - M10	AIR MOTOR	0
37	DIN 931 - M10 x 40	HEX HEAD BOLT	0
38	DIN 7980 - 10	SPRING WASHER	0
39	RRL 1597-27	TRANSFER SHAFT	0
40	NL 10SP	M10 NORDLOCK WASHER LARGE DIAMETER GLUED PAIR	0
41	RRL 1505-17	BRACKET PLATE	0
42	RRL 1597-CV	CONTROL VALVE C/W FITTINGS	0
43	NL 8	M8 NORDLOCK WASHER GLUED PAIR	0
44	ISO 4762 - M8 x 25	HEXAGON SOCKET HEAD CAP SCREW	0
45	NL 8SP	M8 NORDLOCK WASHER LARGE DIAMETER GLUED PAIR	0
46	ISO 4032 - M8	HEX NUT. PRODUCT GRADES A AND B	0
47	RRL 1597-28	THE ROD	0
48	RRL 1597-29	FINION SHAFT	0
49	RRL 1597-30	BRACKET ROD	0
50	PSI789	1 3-8" BLACK RUBBER STOP	0
51	DIN 128 - A 6.4	WASHER	0
52	ISO 4032 - M6	HEX NUT. PRODUCT GRADES A AND B	0
53	DIN 912 - M6 x 50	CYLINDER HEAD CAP SCREW	0
54	RRL 1597-38	SPACER	0
55	RRL 1504-10	SPACER WASHER	0
56	RRL 1503-09	SPACER	0
57	RRL 1503-10	SPACER WASHER	0
58	RRL 1505-11AX	PLAIN WHEEL - ATEX VERSION	0
59	RRL 1504-11AX	GEAR WHEEL - ATEX VERSION	0
60	RRL 1504-11AX	ANTI TIP ROLLER - ATEX VERSION	0




SCALE	MATERIAL	TITLE OF PART	PART NUMBER
NTS		TROLLEY	RRL 1597-01
DESIGNED BY	SIGNATURE	DATE	3 / 4
T. MICHALA (ENR)	19/06/2024	REVISION WEIGHT	UNLESS OTHERWISE SPECIFIED
DRAWN BY	19/06/2024	0 352.8 KG	ALL DIMENSIONS ARE IN MILLIMETERS
CHECKED BY	27/06/2024	REPLACES DRAWING	TOLERANCES
P. SHEWAN	28/06/2024	-	LINEAR
APPROVED BY	28/06/2024	PROFILE NUMBER	UP TO 30.00 ±0.05
P. SHEWAN	28/06/2024	-	OVER 30.00 UP TO 100.00 ±0.10
SHEET SIZE	TITLE OF PROJECT	-	OVER 100.00 UP TO 300.00 ±0.15
A3	TMH20 - 20T 4F LHR	-	OVER 300.00 ±0.20
			ANGULAR ±0.5°
			SURFACE ROUGHNESS √
			IF IN DOUBT ASK

20T 4F LHR TROLLEY - ATEX VERSION



SCALE	MATERIAL	TITLE OF PART			TROLLEY		PART NUMBER	
NTS		(OR EQUIVALENT)					RRL 1597-01	
		SURNAME	DATE	SIGNATURE			4 / 4	
DESIGNED BY	T. MIKOLA-LEWIS	18/06/2024	<i>T. Mikola-Lewis</i>			DATE		19/06/2024
DRAWN BY	T. MIKOLA-LEWIS	19/06/2024	<i>T. Mikola-Lewis</i>			REVISION		0
CHECKED BY	P. SHEWAN	27/06/2024	<i>P. Shewan</i>			WEIGHT		352.8 KG
APPROVED BY	P. SHEWAN	28/06/2024	<i>P. Shewan</i>			REPLACES DRAWING		-
SHEET SIZE		TITLE OF PROJECT					PROFILE NUMBER	
A3		TMH20 - 20T 4F LHR					-	

REVISION HISTORY		
REV.	DATE	APPROVED
0	09/08/2024	PAUL SHEWAN




PARTS LIST			
ITEM QTY	PART NUMBER	DESCRIPTION	REV.
1	RRL 1597-09	LHR M PLATE	0
2	RRL 1597-10	LHR L PLATE	0
3	RRL 1597-11	LHR R PLATE	0
4	RRL 1597-12	YONE PLATE	0
5	RRL 1597-13	CHAIN ANCHOR PLATE L	0
6	RRL 1597-14	CHAIN ANCHOR PLATE R	0
7	RRL 1597-15	CHAIN GUIDE	0
8	RRL 1597-16	CHAIN GUIDE	0
9	RRL 1597-17	CHAIN GUIDE	0
10	RRL 1597-18	LIMIT PADDLE	0
11	RRL 1597-33	HANGER PIN	0
12	NL16SP	M16 NORDLOCK WASHER LARGE DIAMETER GLUED PAIR	0
13	ISO 4032 - M16	HEX NUT, PRODUCT GRADES A AND B	0
14	ISO 4762 - M16 x 90	HEXAGON SOCKET HEAD CAP SCREW	0
15	ISO 4762 - M16 x 110	HEXAGON SOCKET HEAD CAP SCREW	0
16	RRL 1597-31	LINK BAR	0
17	RRL 1597-32	WHEEL AXLE	0
18	RRL 1592-37	PUSHER STUB AXLE	0
19	RRL 1592-26	ANTI ROTATION PLATE	0
20	RRL 1592-28	CHAIN GUIDE - SPACER	0
21	RRL 1592-27	CHAIN GUIDE - SPACER	0
22	RRL 1597-34	SPACER	0
23	RRL 1597-35	SPACER	0
24	RRL 1597-36	SPACER	0
25	NL8	M8 NORDLOCK WASHER GLUED PAIR	0
26	ISO 4762 - M8 x 20	HEXAGON SOCKET HEAD CAP SCREW	0
27	DIN 71412 - AM8 x 1 CONED SHORT	LUBRICATING NIPTLE, CONED TYPE A	0
28	ISO 4762 - M16 x 130	HEXAGON SOCKET HEAD CAP SCREW	0
29	ISO 4762 - M16 x 160	HEXAGON SOCKET HEAD CAP SCREW	0
30	RRL 1597-37	WHEEL AXLE	0
31	RRL 1592-38	ANCHOR PIN	0
32	DIN 913 - M24 x 30	HEXAGON SOCKET SET SCREW	0
33	DIN 125 - A 37	WASHER	0
34	ISO 4035 - M36	HEX NUT, PRODUCT GRADES A AND B	0
35	DIN 7967 M36	M36 SELF-LOCKING NUT	0
36	DIN 913 - M10 x 12	HEXAGON SOCKET SET SCREW	0
37	RRL 15B-01	LIMIT SWITCH BRACKET	0
38	03029302	LIMIT SWITCH	0
39	DIN 912 - M6 x 12	CYLINDER HEAD CAP SCREW	0
40	DIN 912 - M5 x 30	CYLINDER HEAD CAP SCREW	0
41	NL5SP	SPACER RING	0
42	RRL SR1645-01	M5 NORDLOCK WASHER LARGE DIAMETER GLUED PAIR	0
43	RRL PW1645-03	16x45 CHAIN WHEEL	0
44	G40X50X4	NEEDLE BEARING SEAL 40X50X4 - LOW CROSS SECTION	0
45	NK420-20-TV-XL	NEEDLE ROLLER BEARING	0

SCALE		MATERIAL		TITLE OF PART		LHR FRAME		PART NUMBER	
NTS		(OR EQUIVALENT)						RRL 1597-02 1 / 2	
DESIGNED BY		SIGNATURE	DATE	SIGNATURE		DATE		UNLESS OTHERWISE SPECIFIED	
DRAWN BY		T. MICOLAJEWSKI	18/06/2024	T. MICOLAJEWSKI		19/06/2024		ALL DIMENSIONS ARE IN MILLIMETERS	
CHECKED BY		T. MICOLAJEWSKI	19/06/2024	T. MICOLAJEWSKI				TOLERANCES	
APPROVED BY		P. SHEWAN	27/06/2024	P. SHEWAN				LINEAR	
		P. SHEWAN	28/06/2024	P. SHEWAN				UP TO 5 ±0.05	
								OVER 5 TO 30 ±0.1	
								OVER 30 TO 100 ±0.2	
								OVER 100 TO 300 ±0.3	
								OVER 300 TO 500 ±0.5	
								OVER 500 TO 1000 ±0.7	
								OVER 1000 ±1.0	
								OVER 1000 ±1.5	
								OVER 1000 ±2.0	
								OVER 1000 ±3.0	
								OVER 1000 ±4.0	
								OVER 1000 ±5.0	
								OVER 1000 ±6.0	
								OVER 1000 ±7.0	
								OVER 1000 ±8.0	
								OVER 1000 ±9.0	
								OVER 1000 ±10.0	
								OVER 1000 ±12.0	
								OVER 1000 ±15.0	
								OVER 1000 ±20.0	
								OVER 1000 ±25.0	
								OVER 1000 ±30.0	
								OVER 1000 ±40.0	
								OVER 1000 ±50.0	
								OVER 1000 ±60.0	
								OVER 1000 ±70.0	
								OVER 1000 ±80.0	
								OVER 1000 ±90.0	
								OVER 1000 ±100.0	
								OVER 1000 ±120.0	
								OVER 1000 ±150.0	
								OVER 1000 ±200.0	
								OVER 1000 ±250.0	
								OVER 1000 ±300.0	
								OVER 1000 ±400.0	
								OVER 1000 ±500.0	
								OVER 1000 ±600.0	
								OVER 1000 ±700.0	
								OVER 1000 ±800.0	
								OVER 1000 ±900.0	
								OVER 1000 ±1000.0	
								OVER 1000 ±1200.0	
								OVER 1000 ±1500.0	
								OVER 1000 ±2000.0	
								OVER 1000 ±2500.0	
								OVER 1000 ±3000.0	
								OVER 1000 ±4000.0	
								OVER 1000 ±5000.0	
								OVER 1000 ±6000.0	
								OVER 1000 ±7000.0	
								OVER 1000 ±8000.0	
								OVER 1000 ±9000.0	
								OVER 1000 ±10000.0	
								OVER 1000 ±12000.0	
								OVER 1000 ±15000.0	
								OVER 1000 ±20000.0	
								OVER 1000 ±25000.0	
								OVER 1000 ±30000.0	
								OVER 1000 ±40000.0	
								OVER 1000 ±50000.0	
								OVER 1000 ±60000.0	
								OVER 1000 ±70000.0	
								OVER 1000 ±80000.0	
								OVER 1000 ±90000.0	
								OVER 1000 ±100000.0	
								OVER 1000 ±120000.0	
								OVER 1000 ±150000.0	
								OVER 1000 ±200000.0	
								OVER 1000 ±250000.0	
								OVER 1000 ±300000.0	
								OVER 1000 ±400000.0	
								OVER 1000 ±500000.0	
								OVER 1000 ±600000.0	
								OVER 1000 ±700000.0	
								OVER 1000 ±800000.0	
								OVER 1000 ±900000.0	
								OVER 1000 ±1000000.0	
								OVER 1000 ±1200000.0	
								OVER 1000 ±1500000.0	
								OVER 1000 ±2000000.0	
								OVER 1000 ±2500000.0	
								OVER 1000 ±3000000.0	
								OVER 1000 ±4000000.0	
								OVER 1000 ±5000000.0	
								OVER 1000 ±6000000.0	
								OVER 1000 ±7000000.0	
								OVER 1000 ±8000000.0	
								OVER 1000 ±9000000.0	
								OVER 1000 ±10000000.0	
								OVER 1000 ±12000000.0	
								OVER 1000 ±15000000.0	
								OVER 1000 ±20000000.0	
								OVER 1000 ±25000000.0	
								OVER 1000 ±30000000.0	
								OVER 1000 ±40000000.0	
								OVER 1000 ±50000000.0	
								OVER 1000 ±60000000.0	
								OVER 1000 ±70000000.0	
								OVER 1000 ±80000000.0	
								OVER 1000 ±90000000.0	
								OVER 1000 ±100000000.0	
								OVER 1000 ±120000000.0	
								OVER 1000 ±150000000.0	
								OVER 1000 ±200000000.0	
								OVER 1000 ±250000000.0	
								OVER 1000 ±300000000.0	
								OVER 1000 ±400000000.0	
								OVER 1000 ±500000000.0	
								OVER 1000 ±600000000.0	
								OVER 1000 ±700000000.0	
								OVER 1000 ±800000000.0	
								OVER 1000 ±900000000.0	
								OVER 1000 ±1000000000.0	
								OVER 1000 ±1200000000.0	
								OVER 1000 ±1500000000.0	
								OVER 1000 ±2000000000.0	
								OVER 1000 ±2500000000.0	
								OVER 1000 ±3000000000.0	
								OVER 1000 ±4000000000.0	
								OVER 1000 ±5000000000.0	
								OVER 1000 ±6000000000.0	
								OVER 1000 ±7000000000.0	
								OVER 1000 ±8000000000.0	
								OVER 1000 ±9000000000.0	
								OVER 1000 ±10000000000.0	
								OVER 1000 ±12000000000.0	
								OVER 1000 ±15000000000.0	
								OVER 1000 ±20000000000.0	
								OVER 1000 ±25000000000.0	
								OVER 1000 ±30000000000.0	
								OVER 1000 ±40000000000.0	
								OVER 1000 ±50000000000.0	
								OVER 1000 ±60000000000.0	
								OVER 1000 ±70000000000.0	
								OVER 1000 ±80000000000.0	
								OVER 1000 ±90000000000.0	
								OVER 1000 ±100000000000.0	
								OVER 1000 ±120000000000.0	
								OVER 1000 ±150000000000.0	
								OVER 1000 ±200000000000.0	
								OVER 1000 ±250000000000.0	
								OVER 1000 ±300000000000.0	
								OVER 1000 ±400000000000.0	
								OVER 1000 ±500000000000.0	
								OVER 1000 ±600000000000.0	
								OVER 1000 ±700000000000.0	
								OVER 1000 ±800000000000.0	
								OVER 1000 ±900000000000.0	
								OVER 1000 ±1000000000000.0	
								OVER 1000 ±1200000000000.0	
								OVER 1000 ±1500000000000.0	
								OVER 1000 ±2000000000000.0	
								OVER 1000 ±2500000000000.0	
								OVER 1000 ±3000000000000.0	
								OVER 1000 ±4000000000000.0	
								OVER 1000 ±5000000000000.0	
								OVER 1000 ±6000000000000.0	
								OVER 1000 ±7000000000000.0	
								OVER 1000 ±8000000000000.0	
								OVER 1000 ±9000000000000.0	
								OVER 1000 ±10000000000000.0	
								OVER 1000 ±12000000000000.0	
								OVER 1000 ±15000000000000.0	
								OVER 1000 ±20000000000000.0	
								OVER 1000 ±25000000000000.0	
								OVER 1000 ±30000000000000.0	
								OVER 1000 ±40000000000000.0	
								OVER 1000 ±50000000000000.0	
								OVER 1000 ±60000000000000.0	
								OVER 1000 ±70000000000000.0	
								OVER 1000 ±80000000000000.0	
								OVER 1000 ±90000000000000.0	
								OVER 1000 ±100000000000000.0	
								OVER 1000 ±120000000000000.0	
								OVER 1000 ±150000000000000.0	
								OVER 1000 ±200000000000000.0	
								OVER 1000 ±250000000000000.0	
								OVER 1000 ±300000000000000.0	
								OVER 1000 ±400000000000000.0	
								OVER 1000 ±500000000000000.0	
								OVER 1000 ±600000000000000.0	
								OVER 1000 ±700000000000000.0	
								OVER 1000 ±800000000000000.0	
								OVER 1000 ±900000000000000.0	
								OVER 1000 ±1000000000000000.0	
								OVER 1000 ±1200000000000000.0	
								OVER 1000 ±1500000000000000.0	
								OVER 1000 ±2000000000000000.0	
								OVER 1000 ±2500000000000000.0	
								OVER 1000 ±3000000000000000.0	
								OVER 1000 ±4000000000000000.0	
								OVER 1000 ±5000000000000000.0	
								OVER 1000 ±6000000000000000.0	
								OVER 1000 ±7000000000000000.0	
								OVER 1000 ±8000000000000000.0	
								OVER 1000 ±9000000000000000.0	
								OVER 1000 ±10000000000000000.0	
								OVER 1000 ±12000000000000000.0	
								OVER 1000 ±15000000000000000.0	
								OVER 1000 ±20000000000000000.0	
								OVER 1000 ±25000000000000000.0	
								OVER 1000 ±30000000000000000.0	
								OVER 1000 ±40000000000000000.0	

VIEW "A"



VIEW "A"



SCALE		MATERIAL		TITLE OF PART		PART NUMBER	
NTS		(SEE EQUIVALENT)		LHR FRAME		RRL 1597-02 2 / 2	
DESIGNED BY		DATE		DATE		UNLESS OTHERWISE SPECIFIED	
DRAWN BY		SIGNATURE		19/06/2024		ALL DIMENSIONS ARE IN MILLIMETERS	
CHECKED BY		T. MYKOLAJEWSKI		0		TOLERANCES	
APPROVED BY		P. SHEWAN		0		LINEAR	
SHEET SIZE		27/06/2024		0		ANGULAR	
TITLE OF PROJECT		28/06/2024		0		OTHER THAN 10:1	
A3		TMH20 - 20T 4F LHR		REPLACES DRAWING		OTHER THAN 10:1	
				PROFILE NUMBER		OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	
						OTHER THAN 10:1	

DRIVE UNIT FOR THE VERSION WITHOUT A CHAIN COLLECTOR



REVISION HISTORY		
REV.	DATE	APPROVED
0	09/08/2024	PAUL SHEWAN



DRIVE UNIT FOR THE VERSION WITHOUT A CHAIN COLLECTOR - PARTS LIST				DRIVE UNIT FOR THE VERSION WITHOUT A CHAIN COLLECTOR - PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION	REV.	ITEM	QTY	PART NUMBER
22	1	425828N20	LIMIT LEVER D		1	1	425828350
23	1	426303X60	CHAIN SET SPINDLE		2	1	TMH-10 AM
24	3	130705035	CHAIN SET PLATE SHAFT		3	1	TMH-10 GB
25	2	426303X50	CHAIN SET PLATE SHAFT		4	1	425828M80
26	1	131710130	HEXAGON SOCKET HEAD CAP SCREW M10X130		5	1	425828M90
27	1	131307010	WASHER M10		6	1	TMH-10 CV
28	1	134501010	U NUT M10		7	2	13103005
29	1	426303X80	CHAIN END PIN		8	1	13101068
30	1	130704032	SPLIT PIN 4X32		9	1	425828A50
34	2	426303X50	WASHER PIN		10	1	130104004
35	2	426303X60	WASHER PIN		11	1	425828Q20
36	2	131301016	SPRING WASHER M16		12	3	426301L60
37	2	134501016	U NUT M16		13	1	425806200
42	4	131710025	HEXAGON SOCKET HEAD CAP SCREW M10X25		14	1	130115015
43	1	PEB-01	PENDANT BRACKET (TMH-3000 & TMH-10)	0	15	1	426303R40
44	4	KG21.06-01NS	1/8" BSP MALE TO 6MM PUSH FIT ELBOW		16	1	426303X40
45	4	FEL02NP	1/8" FEMALE ELBOW		17	5	131716140
46	4	100-0202	1/8" MALE TO 1/8" MALE NIPPLE		18	5	131310016
47	1	426301L40	CHAIN SEPARATOR PIN		19	2	132106006
48	2	RRL 1588-08	SPACER	0	20	1	426301X70

SCALE		MATERIAL		TITLE OF PART		DRIVE UNIT		PART NUMBER	
NTS		(OR EQUIVALENT)						RRL 1597-DU 1 / 2	
DESIGNED BY		DATE		SIGNATURE		DATE		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN MILLIMETERS	
DRAWN BY		T. MYKOLAWSKI		20/06/2024		20/06/2024		TELEPHONE	
CHECKED BY		P. SHEWAN		27/06/2024		0		UP TO 5 ±0.05 OVER 5 TO 10 ±0.1 OVER 10 TO 20 ±0.15 OVER 20 TO 40 ±0.2 OVER 40 TO 60 ±0.25 OVER 60 TO 100 ±0.3	
APPROVED BY		P. SHEWAN		28/06/2024		127.0 KG		OVER 100 ±0.5	
SHEET SIZE		TITLE OF PROJECT		REPLACES DRAWING		-		ANGULAR ±0.5°	
A3		TMH20 - 20T 4F LHR		PROFILE NUMBER		-		SURFACE ROUGHNESS $\sqrt{R}$ IF IN DOUBT ASK	

DRIVE UNIT FOR THE VERSION WITH A CHAIN COLLECTOR




DRIVE UNIT FOR THE VERSION WITH A CHAIN COLLECTOR - PARTS LIST				DRIVE UNIT FOR THE VERSION WITH A CHAIN COLLECTOR - PARTS LIST			
ITEM QTY	PART NUMBER	DESCRIPTION	REV.	ITEM QTY	PART NUMBER	DESCRIPTION	REV.
20	426301X70	CHAIN END CONNECTOR	1	1	426828350	CHAIN GUIDE	1
22	426828N20	LIMIT LEVER D	2	1	TMH-10 AM	AIR MOTOR	1
23	426303X60	CHAIN SET SPINDLE	3	1	TMH-10 GB	GEAR BOX	1
24	130705035	SPLIT PIN 5X35	4	1	426828M80	MIDDLE PLATE G	1
25	426301X50	CHAIN SET PLATE SHAFT	5	1	426828M90	MIDDLE PLATE M	1
26	131701030	HEXAGON SOCKET HEAD CAP SCREW M10X30	6	1	TMH-10 CV	CONTROL VALVE	1
27	131507010	WASHER M10	7	2	131030005	O-RING S-7	2
28	134501010	U NUT M10	8	1	131010068	O-RING P-100	1
29	426301X80	CHAIN END PIN	9	1	426828A50	LOAD SHEAVE	1
30	130704032	SPLIT PIN 4X32	10	1	130104004	BEARING 6003	1
42	131700025	HEXAGON SOCKET HEAD CAP SCREW M10X25	11	1	426828Q20	BEARING COVER	1
43	PEB-01	PENDANT BRACKET (TMH-3000 & TMH-10)	0	3	426301L60	KNOCK PIN	3
44	K02L06-01NS	1/8" BSP MALE TO 6MM PUSH FIT ELBOW	13	1	13015015	COUPLING	1
45	FEL02NP	1/8" FEMALE ELBOW	14	1	13015015	CHAIN SEPARATOR	1
46	100-0202	1/8" MALE TO 1/8" MALE NIPPLE	15	1	426303R40	CHAIN SET PLATE	1
47	426301U40	CHAIN SEPARATOR PIN	16	5	426303X40	HEXAGON SOCKET HEAD CAP SCREW M16X40	5
48	NL16	SPACER	17	5	131716140	SPRING WASHER M16	5
49	1588-08	M16 NORDLOCK WASHER GLUED PAIR	18	5	131310016	HEX SOCKET SET SCREW M6X6	5
50	ISO 4762 - M16 X 50	HEXAGON SOCKET HEAD CAP SCREW	19	2	132106006	HEX SOCKET SET SCREW M6X6	2
51	TMH-10-BB-06	HOOK PIN	0				

SCALE	MATERIAL	TITLE OF PART	DRIVE UNIT	PART NUMBER
NTS	(SEE EXPLANATION)			RRL /597-DU
DESIGNED BY	T. MYKOLAJEWSKI	DATE	20/06/2024	2 / 2
DRAWN BY	T. MYKOLAJEWSKI	REVISION WEIGHT	0 / 127.0 KG	
CHECKED BY	P. SIEWIAN	REPLACES DRAWING	-	
APPROVED BY	P. SIEWIAN	PROFILE NUMBER	-	
SHEET SIZE	A3	TMH20 - 20T 4F LHR		

RED ROOSTER LIFTING
WARTA WIELKA, 100-000
TEL. 22 630 10 00
WWW.ROOSTERLIFTING.COM

UNLESS OTHERWISE SPECIFIED:
ALL DIMENSIONS IN MILLIMETERS
TOLERANCES:
LINEAR
OTHER THAN 10 TO 300
OTHER THAN 300 TO 1000
OTHER THAN 1000 TO 4000
SURFACE ROUGHNESS
IF IN DOUBT ASK

REVISION HISTORY		
REV.	DATE	APPROVED
0	19/11/2020	B. AITKEN




PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	425806790	MOTOR CASE
2	1	425806150	ROTOR
3	1	130302050	RETAINING RING S-50
4	1	425806008	SILENCER M C/P
5	1	425806080	REAR PLATE
6	1	425806170	FRONT PLATE
7	1	137102033	VANE
8	8	130605020	SPRING PIN 5x20
9	1	425806160	CYLINDER
10	1	130802235	LIFT SPRING
11	1	425806160	LIMIT RETAINER B
12	1	425806250	SPRING SEAT
13	1	130802226	SPRING 13x67x2
14	1	425806140	LIMIT SPOOL
15	1	425806130	LIMIT SPOOL BUSHING
16	1	425806150	LIMIT RETAINER F
17	4	137103022	O-RING S-28
18	1	137103016	O-RING S-20
19	1	130301032	RETAINING RING H-32
20	1	132306050	HEX SOCKET HEAD CAP SCREW M6x50
21	1	134403106	HEX NUT M6
22	1	136102172	MOTOR GASKET
23	1	130321013	DUST SEAL OSZ2294
24	2	130321016	NEEDLE BEARING TA2215Z
25	1	425806190	LIMIT WASHER
26	2	137103029	O-RING S-36
27	1	137103021	LIMIT SHAFT
28	1	425806440	O-RING S-26
29	1	425806160	LIMIT SHAFT BUSHING
30	1	130303005	BEARING 600ZZ
31	2	130303020	ROLLER SHAFT E-4
32	4	130303025	ROLLER PIN 2.5x25
33	1	130303025	RETAINING RING H-40
34	1	130303010	LIMIT PLUG
35	1	130303013	O-RING S-5
36	1	130605010	SPRING PIN 5x10
37	2	425828510	CORD LEVER
38	1	137107012	WASHER M12
39	1	134501012	LIMIT NUT
40	1	130603005	SPRING PIN 3x5
41	2	130104011	BEARING 6010

SCALE		TITLE OF PART		PART NUMBER	
NTS		AIR MOTOR		TMH-10 AM / /	
(OR EQUIVALENT)		DATE		UNLESS OTHERWISE SPECIFIED TOLERANCES	
SURNAME		SIGNATURE		ALL DIMENSIONS ARE IN MILLIMETERS	
O. MORGAN		09/10/2020		UP TO 5 ± 0.05	
O. MORGAN		19/11/2020		OVER 5 TO 10 ± 0.1	
W. MORRISON		20/1/2020		OVER 10 TO 25 ± 0.15	
B. AITKEN		23/1/2020		OVER 25 TO 50 ± 0.2	
TITLE OF PROJECT		REPLACES DRAWING		OVER 50 TO 100 ± 0.3	
TMH10 - 10T 2F AH		-		OVER 100 ± 0.5	
SHEET SIZE		PROFILE NUMBER		ANGULAR ±0.5°	
A3		-		SURFACE ROUGHNESS √ IF IN DOUBT ASK	




TMH10 - 10T 2F AH

REVISION HISTORY		
REV.	DATE	APPROVED
0	19/11/2020	B. AITKEN




PARTS LIST				
ITEM	QTY	PART NUMBER	DESCRIPTION	REV.
1	1	425628310	GEAR CASE	
2	1	425628460	FIRST PINION	
3	1	426301080	CHAIN GUIDE COVER	
4	1	13015275	BEARING 6215 DDU	
5	10	13103005	O-RING S-7	
6	1	426501060	THIRD INTERNAL GEAR	
7	1	4265028240	CAGE	
8	3	425628240	THIRD STAR GEAR	
9	3	150180904	NEEDLE BEARING RN16004	
10	3	426501050	THIRD IDLE GEAR SHAFT	
11	2	13016024	BEARING 16024	
12	1	426501060	INTERNAL GEAR SPACER	
13	1	426501060	THIRD PINION	
14	3	4265028240	SECOND STAR GEAR	
15	3	150180904	NEEDLE BEARING 142320	
16	3	426501050	SECOND IDLE GEAR SHAFT	
17	3	426501060	SECOND INTERNAL GEAR	
18	1	426501050	CONED DISC SPRING	
19	1	426501050	O-RING ASSY 60037Z	
20	1	13015009	FIRST RING GEAR	
21	1	4265028240	SECOND PINION	
22	1	4265028240	FIRST PIN	
23	3	426501060	NEEDLE BEARING 141512Z	
24	3	426501060	WASHER MILL	
25	3	130150153	RETAINING RING S-15	
26	3	130150153	BEARING 60037Z	
27	3	130150153	BRAKE PLATE	
28	1	130150153	O-RING S-155	
29	1	426501060	HEX SOCKET HEAD CAP SCREW M6X25	
30	1	13117242	BRAKE DISC	
31	1	13103063	SPRING 20.5X21.9X2.9	
32	1	13103063	O-RING ASSY 60037Z	
33	4	13103063	BRAKE PISTON	
34	1	426501060	HEX SOCKET SFT SCREW M5X5	
35	1	130150153	HEX SOCKET HEAD CAP SCREW M6X10	
36	8	130150153	O-RING S-145	
37	1	13117255	HEX SOCKET SFT SCREW M5X5	
38	1	426501060	HEX SOCKET HEAD CAP SCREW M6X10	
39	2	132105005	O-RING S-145	
40	4	13103065		
41	1	13103065		
TITLE OF PART				
GEAR BOX				
PART NUMBER				
TMH-10 GB				
1 / 1				
UNLESS OTHERWISE SPECIFIED				
ALL DIMENSIONS ARE IN MILLIMETERS				
TOLERANCES				
LINEAR				
OVER 30 UP TO 100 ±0.1				
OVER 100 UP TO 300 ±0.15				
OVER 300 UP TO 500 ±0.2				
OVER 500 UP TO 1000 ±0.3				
OVER 1000 UP TO 2000 ±0.5				
ANGULAR ±0.5°				
SURFACE ROUGHNESS				
IF IN DOUBT ASK				
DESIGNED BY				
O. MORGAN				
DRAWN BY				
O. MORGAN				
CHECKED BY				
W. MORRISON				
APPROVED BY				
B. AITKEN				
SHEET SIZE				
A3				
TITLE OF PROJECT				
GEAR BOX				
DATE				
19/11/2020				
REVISION WEIGHT				
0 41.7 KG				
REPLACES DRAWING				
-				
PROFILE NUMBER				
-				

REVISION HISTORY		
REV.	DATE	APPROVED
0	19/11/2020	B. AITKEN






PARTS LIST		
ITEM	QTY	DESCRIPTION
1	1	VALVE BODY
2	2	BUSH CAP
3	2	O-RING S-20
4	1	VALVE BUSHING (D)
5	4	SPRING PIN 3x5
6	4	O-RING S-30
7	2	SPRING 11.4x10x1.4
8	2	THRUSTLE VALVE
9	2	O-RING ASS68-115
10	2	O-RING ASS68-113 (HS90)
11	4	O-RING S-32
12	4	O-RING S-7
13	1	VALVE BUSHING (U)
14	2	RETAINING RING H-36
15	2	PISTON
16	2	SPRING 26 x32x2.6
17	2	SPRING SEAT
18	2	RETAINING RING S-12
19	2	VALVE CAP
20	2	BEARING 105x107
21	2	RETAINING RING H-40
22	2	SILENCER (SS)
23	1	SILENCER (F)
24	2	SILENCER (SL)
25	1	EXHAUST FLATE
26	5	HEX SOCKET BUTTON HEAD SCREW M5X10
27	1	VALVE GASKET
28	2	HEX SOCKET SET SCREW M6X6
29	8	HEX SOCKET SET SCREW M6X5
30	1	UNDER COVER
31	1	MAIN CUT SEAT
32	1	O-RING ASS68-030
33	3	MAIN CUT SEAT
34	1	MAIN CUT HOLDER
35	1	HEX SOCKET HEAD CAP SCREW M6X8
36	1	MAIN CUT VALVE
37	1	O-RING S-25
38	2	O-RING S-35
39	1	MAIN CUT CAP
40	1	O-RING S-26
41	1	RETAINING RING H-47
42	1	O-RING ASS68-134
43	1	INLET BUSHING CP
44	1	HEX SOCKET HEAD PLUG PT3/4
45	1	HEX SOCKET SET SCREW M5X22
46	2	HEX NUT M5
47	2	SPRING PIN 5X10
48	2	HEX SOCKET HEAD CAP SCREW M6X25
49	4	PILOT SILENCER
50	1	CROSS-RECESSED HEAD SCREW M5X6
51	4	HEX SOCKET HEAD CAP SCREW M6X65
52	1	HEX SOCKET HEAD CAP SCREW M6X50
53	3	HEX SOCKET HEAD CAP SCREW M6X50
SCALE		TITLE OF PART
NTS		CONTROL VALVE
DESIGNED BY		DATE
O. MORGAN		19/11/2020
DRAWN BY		REVISION WEIGHT
O. MORGAN		0 13.1 KG
CHECKED BY		REPLACES DRAWING
W. MORRISON		-
APPROVED BY		PROFILE NUMBER
B. AITKEN		-
SHEET SIZE		TMH-10 CV
A3		1 / 1
		UNLESS OTHERWISE SPECIFIED
		ALL DIMENSIONS ARE IN MILLIMETERS
		TOLERANCES
		LINEAR
		OVER 10 UP TO 100 ±0.1
		OVER 100 UP TO 1000 ±0.2
		OVER 1000 UP TO 10000 ±0.5
		OTHER SURFACES TO 0.05
		ANGULAR ±0.5°
		SURFACE ROUGHNESS
		IF IN DOUBT ASK

REVISION HISTORY		
REV.	DATE	APPROVED
0	09/08/2024	PAUL SHEWAN



ITEM QTY		PART NUMBER	DESCRIPTION	REV.
1	2	RRL 1594-17	BOTTOM BLOCK - SIDE PLATE	1
2	1	RRL 1594-18	BOTTOM BLOCK - MID PLATE	1
3	4	RRL 1594-19	CHAIN GUIDE	0
4	1	RRL 1594-23	HOOK HOLDER	0
5	1	RRL 1594-24	HOOK HOLDER ON	0
6	2	RRL 1594-41	WHEEL SHAFT	0
7	2	RRL 1594-42	LOAD BAR	0
8	2	RRL 1594-43	TIE ROD	0
9	2	RRL 1594-44	CHAIN GUIDE	1
10	2	RRL 1594-45	FREE CHAIN WHEEL	1
11	1	RRL 1594-46	HOOK TRUST RING (BOTTOM BLOCK)	1
12	2	RRL 1538-36	ANTI ROTATION PLATE	0
13	2	RRL 1538-37	CHAIN GUIDE - SPACER	0
14	1	RRL 1592-26	NEEDLE BEARING SEAL 40x50x4 - LOW CROSS SECTION	0
15	1	RRL 1592-27	NEEDLE ROLLER BEARING	0
16	8	RRL 1592-28	THRUST BALL BEARINGS SINGLE DIRECTION SKF	0
17	16	RRL 1592-29	HEX NUT - PRODUCT GRADES A AND B	0
18	3	DIN 71412 - A13 X1 CONED SHORT	LUBRICATING NIPPLE CONED TYPE A	0
19	4	6x0.50x4	NEEDLE BEARING SEAL 40x50x4 - LOW CROSS SECTION	0
20	6	NK40-20-T1-XL	HEXAGON SOCKET SET SCREW	0
21	1	DIN 913 - M6 X 8	HEX NUT - PRODUCT GRADES A AND B	0
22	1	DIN 711 SKF - SKF 5/118	HEX NUT - PRODUCT GRADES A AND B	0
23	4	DIN 128 - A 31	M16 NORDLOCK WASHER LARGE DIAMETER GLUED PAIR	0
24	8	ISO 4035 - M30	M8 NORDLOCK WASHER GLUED PAIR	0
25	4	DIN EN ISO 1234 - 5x35	HEXAGON SOCKET HEAD CAP SCREW	0
26	8	NI 6SP	M10 NORDLOCK WASHER GLUED PAIR	0
27	8	ISO 4032 - M16	HEX NUT - PRODUCT GRADES A AND B	0
28	2	NI 8	SPACER RING	0
29	2	ISO 4762 - M8 X 20	16x2.5 CHAIN WHEEL	0
30	4	NI 10		
31	4	ISO 4032 - M10		
32	2	RRL SR1645-01		
33	1	RRL PW1645-03		
SCALE		TITLE OF PART		
NTS		BOTTOM BLOCK		
DESIGNED BY		SIGNATURE	DATE	DATE
DRAWN BY		T. MICHAELSON	19/06/2024	19/06/2024
CHECKED BY		P. SHEWAN	27/06/2024	27/06/2024
APPROVED BY		P. SHEWAN	28/06/2024	28/06/2024
SHEET SIZE		TITLE OF PROJECT		
A3		TMH20 - 20T 4F LHR		
		REPLACES DRAWING		
		PROFILE NUMBER		
		-		
		REVISION WEIGHT		
		0		
		REVISION DATE		
		19/06/2024		
		UNLESS OTHERWISE SPECIFIED		
		ALL DIMENSIONS ARE IN MILLIMETERS		
		TOLERANCES		
		LINEAR		
		OTHER THAN 0 TO 0.05		
		OTHER THAN 0 TO 0.05		
		OTHER THAN 0 TO 0.05		
		OTHER THAN 0 TO 0.05		
		ANGULAR $\pm 0.5^\circ$		
		SURFACE ROUGHNESS $\sqrt{R}$		
		IF IN DOUBT ASK		

REVISION HISTORY		
REV.	DATE	APPROVED
0	09/08/2024	PAUL SHEWAN






PARTS LIST			
ITEM QTY	PART NUMBER	DESCRIPTION	REV.
1	VJJ-4603-2B	VERSA PNEUMATIC DIRECTIONAL VALVE	
2	ANAT-06	3/4" SILENCER	
3	MFL12NP	3/4" MALE TO FEMALE ELBOW	
4	MFL02NP	1/8" MALE TO FEMALE ELBOW	
5	100-0202	1/8" MALE TO 1/8" MALE NIPPLE	
6	P068	3/4" PARALLEL M/M NIPPLE	

SCALE 1:2,5		MATERIAL		TITLE OF PART CONTROL VALVE C/W FITTINGS		PART NUMBER RRL 1597-CV 1 / 1	
DESIGNED BY		SURNAME		DATE		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN MILLIMETERS	
DRAWN BY		T. MIKOLAJEWSKI		18/06/2024		TOLERANCES LINEAR UP TO 5 $\pm 0,15$ OVER 5 UP TO 30 $\pm 0,2$ OVER 30 UP TO 120 $\pm 0,5$ OVER 120 UP TO 500 $\pm 0,8$ OVER 500 UP TO 1000 $\pm 1,5$ ANGULAR $\pm 0,5^\circ$	
CHECKED BY		T. MIKOLAJEWSKI		20/06/2024		SURFACE ROUGHNESS $\sqrt{}$ IF IN DOUBT ASK	
APPROVED BY		P. SHEWAN		27/06/2024			
SHEET SIZE		P. SHEWAN		28/06/2024			
A4		TITLE OF PROJECT		DATE			
		TMH20 - 20T 4F LHR		REVISION			
				0		8,4 KG	
				REPLACES DRAWING			
				-			
				PROFILE NUMBER			
				-			

RRI-VTP4 - 4 STATION PENDANT C/W EMERGENCY STOP VALVE (BIK3206P-BS54)




REV.	DATE	APPROVED
0	21/03/2024	PAUL SHEWAN

REVISION HISTORY
REV. DATE APPROVED
0 21/03/2024 PAUL SHEWAN



RRI-VTP4 - 4 STATION PENDANT C/W EMERGENCY STOP VALVE (BIK3206P-BS54) - PARTS LIST			REV.
ITEM QTY	PART NUMBER	DESCRIPTION	0
1	RRI-VTP4-01	FRONT CASE	
2	XACA04-02	REAR CASE	
3	XACA04-03	RUBBER SEAL	
4	XACB02-04	PROTECTIVE CABLE SLEEVE	
5	XACB02-05	PROTECTIVE CABLE SLEEVE MOUNTING I	
6	XACB02-06	PROTECTIVE CABLE SLEEVE MOUNTING II	
7	XACB02-07	PROTECTIVE CABLE SLEEVE MOUNTING I - BRACKET	
8	XACB02-08	PROTECTIVE CABLE SLEEVE MOUNTING II - HANGER	
9	XACB02-09	CASE ENCLOSURE NET	
10	XACB02-10	CROSS RECESSED PAN HEAD TAPPING SCREW 3.5X25	
11	XACB02-11	SLOTTED CHEESE HEAD SCREW M6X25	
12	XACB02-12	SLOTTED CHEESE HEAD SCREW M4X16	
13	XACB02-13	WASHER M4	
14	XACB02-14	PLASTIC WASHER M4	
15	RRI-LABEL-REDROOSTER	RED ROOSTER LABEL	0
16	RRI-LABEL-E-STOP	EMERGENCY STOP LABEL	0
17	E-STOP-GUARD/001	YELLOW E-STOP GUARD	
18	XAC-B4-LEGEND-UP	UP LEGEND	
19	XAC-B4-LEGEND-DOWN	DOWN LEGEND	
20	XAC-B4-LEGEND-RIGHT	RIGHT LEGEND	
21	XAC-B4-LEGEND-LEFT	LEFT LEGEND	
22	BIK-3209-P-VALVE	BUTTON VALVE	
23	BIK-3209-234-B-COVER	BUTTON COVER	
24	P080	Y- BRANCH	
25	P086	1/8" BSP TO 4MM PUSH FIT	
26	P087	1/8" BSP TO 6MM PUSH FIT	
27	P089	SLOTTED CHEESE HEAD SCREW M4X20	
28	P12	6MM DOUBLE Y- BRANCH	
29	P18	HEX NYLOC NUT M4	
30	P30	6MM-6MM REDUCER	
31	301P	1/8" BSP TO 6MM PUSH FIT ELBOW	
32	304P	6MM POLYURETHANE TUBES	
33	HP7	4MM POLYURETHANE TUBES	
34	HP8	3/4" BRAIDED PVC AIR HOSE	
35	HP4	STIFFENER	
36	RRI-VTP2-02	EMERGENCY STOP VALVE AND BUTTON	0
37	BIK3206P-BS54	GENERAL ASSEMBLY	
SCALE	MATERIAL	TITLE OF PART	PART NUMBER
NTS		GENERAL ASSEMBLY	RRI-VTP4-00
DESIGNED BY	SURNAME	DATE	07/11/2023
DRAWN BY	R. TWOREK	REVISION	0
CHECKED BY	T. MINOLARSKI	REPLACES DRAWING	3.0 KG
APPROVED BY	P. SHEWAN	PROFILE NUMBER	-
SHEET SIZE	A3	TITLE OF PROJECT	RRI-VTP4 - 4 STATION PENDANT
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			




RRI-VTP4 - 4 STATION PENDANT C/W EMERGENCY STOP VALVE (S406-MJV03-ASSY)



RRI-VTP4 - 4 STATION PENDANT C/W EMERGENCY STOP VALVE (S406-MJV03-ASSY) - PARTS LIST			
ITEM QTY	PART NUMBER	DESCRIPTION	REV.
1	RRI-VTP4-01	FRONT CASE	0
2	XACA02-02	RUBBER SEAL	
3	XACA02-04	PROTECTIVE CABLE SLEEVE	
4	XALB02-05	PROTECTIVE CABLE SLEEVE MOUNTING I	
5	XALB02-06	PROTECTIVE CABLE SLEEVE MOUNTING II	
6	XALB02-07	PROTECTIVE CABLE SLEEVE MOUNTING I - BRACKET	
7	XALB02-08	PROTECTIVE CABLE SLEEVE MOUNTING II - HANGER	
8	XALB02-09	CASE ENCLOSURE KEY	
9	XALB02-10	CROSS RECESSED PAN HEAD TAPPING SCREW 3.5X25	
10	XALB02-11	SLOTTED CHEESE HEAD SCREW M6X25	
11	XALB02-12	SLOTTED CHEESE HEAD SCREW M4X14	
12	XALB02-13	WASHER M4	
13	XALB02-14	PLATE WASHER M4	
14	RRI-LABEL-REDROOSTER	RED ROOSTER LABEL	0
15	RRI-LABEL-STOP	EMERGENCY STOP LABEL	0
16	RRI-LABEL-STOP	YELLOW STOP LABEL	
17	RRI-LABEL-STOP	UP LEGEND	
18	XAC-B-L-LEGEND-UP	DOWN LEGEND	
19	XAC-B-L-LEGEND-DOWN	RIGHT LEGEND	
20	XAC-B-L-LEGEND-RIGHT	LEFT LEGEND	
21	XAC-B-L-LEGEND-LEFT	BUTTON VALVE	
22	BIK-3209-F-VALVE	BUTTON COVER	
23	BIK-3209-F-VALVE	Y1 BRANCH	
24	F080	1/8" BSP TO 4MM PUSH FIT	
25	F080	1/8" BSP TO 6MM PUSH FIT	
26	F087	1/8" BSP TO 6MM PUSH FIT	
27	105P	SLOTTED CHEESE HEAD SCREW M4X20	
28	P112	6MM DOUBLE Y1 BRANCH	
29	P118	6MM PLUG IN ELBOW	
30	135-IP	HEX NYLOC NUT M4	
31	301P	8MM-6MM REDUCER	
32	304P	1/8" BSP TO 6MM PUSH FIT ELBOW	
33	HP7	6MM POLYURETHANE TUBES	
34	HP8	4MM POLYURETHANE TUBES	
35	HP4	3/4" BRAIDED PVC AIR HOSE	
36	RRI-VTP2-02	STIFFENER	
37	S406-MJV03-ASSY	EMERGENCY STOP VALVE AND BUTTON	
38			
SCALE			PART NUMBER
NTS			RRI-VTP4-00
TITLE OF PART			2 / 2
GENERAL ASSEMBLY			
DESIGNED BY	DATE	SIGNATURE	DATE
R. THORP	25/10/2023	R. Thorp	07/11/2023
DRAWN BY	DATE	SIGNATURE	REVISION WEIGHT
R. THORP	07/11/2023	R. Thorp	0 3.0 KG
CHECKED BY	DATE	SIGNATURE	REPLACES DRAWING
T. MCKALEWSKI	08/11/2023	T. McKalewski	-
APPROVED BY	DATE	SIGNATURE	PROFILE NUMBER
P. SIEMAN	09/11/2023	P. Sieman	-
TITLE OF PROJECT			
RRI-VTP4 - 4 STATION PENDANT			
SHEET SIZE			
A3			
UNLESS OTHERWISE SPECIFIED			
ALL DIMENSIONS ARE IN MILLIMETERS			
TOLERANCES			
LINEAR			
OVER 30 UP TO 50.0			
OVER 50 UP TO 100.0			
OVER 100 UP TO 300.0			
OVER 300 UP TO 1000.0			
ANGULAR ±0.5°			
SURFACE ROUGHNESS			
IF IN DOUBT ASK			




RRI-VTP4-M - 4 STATION PENDANT C/W EMERGENCY STOP VALVE (BIK3206P-BS54)

REVISION HISTORY		
REV.	DATE	APPROVED
0	21/03/2024	PAUL SHEWAN




RRI-VTP4-M - 4 STATION PENDANT C/W EMERGENCY STOP VALVE (BIK3206P-BS54) - PARTS LIST		
ITEM QTY	PART NUMBER	DESCRIPTION
1	RRI-VTP4-M-01	FRONT CASE
2	XACA01-02	RUBBER SEAL
3	XACA01-03	WASHER M4
4	XALC02-12	SLOTTED CHEESE HEAD SCREW M4X14
5	XALC02-13	WASHER M4
6	XALC02-14	PLASTIC WASHER M4
7	RRI-VTP4-M-02	RED ROOSTER LIFTING
8	RRI-VTP4-M-03	EMERGENCY STOP LABEL
9	RRI-VTP4-M-04	YELLOW E-STOP GUARD
10	BIK3206P-BS54	EMERGENCY STOP VALVE AND BUTTON
11	XALC02-15	DOWN LEGEND
12	XALC02-16	RIGHT LEGEND
13	XALC02-17	LEFT LEGEND
14	XALC02-18	BUTTON VALVE
15	BIK3206P-BS54	BUTTON COVER
16	BIK3206P-BS54	Y1 BRANCH
17	P087	1/8" BSP TO 6MM PUSH FIT
18	105P	SLOTTED CHEESE HEAD SCREW M4X20
19	P112	6MM DOUBLE Y1 BRANCH
20	P118	6MM PLUG IN ELBOW
21	135-IP	HEX NYLOC NUT M4
22	135-IP	8MM-6MM REDUCER
23	304P	1/8" BSP TO 6MM PUSH FIT ELBOW
24	HP7	6MM POLYURETHANE TUBES
25	RRI-VTP4-M-02	PENDANT BRACKET
26	ISO 4018 - M6 x 25	HEX-HEAD BOLT
27	139P	HEX NYLOC NUT M6
28	145P	FLAT WASHER M6
29	P245	6MM TO 1/8" BSP BULHEAD ADAPTOR
30	P071-I	1/8" BSP HEX NIPPLE C/W 60° CONE
31	P071-I	1/8" BSP TO 1/4" SWIVEL HOSE TAIL
32	P016-I	1/4" ANTI-STATIC 20BAR BLACK AIR HOSE (BS EN ISO 2398:2016)
33	I-4 HOSE	1/4" HOSE FERRULE (GALVANISED)
34	P002-I	
MATERIAL		TITLE OF PART
SCALE	NTS	GENERAL ASSEMBLY
DESIGNED BY	R. THORPE	SIGNATURE
DRAWN BY	R. THORPE	DATE
CHECKED BY	T. MCKELWEN	09/11/2023
APPROVED BY	P. SHEWAN	09/11/2023
SHEET SIZE	A3	TITLE OF PROJECT
RRI-VTP4-M - 4 STATION PENDANT		RRI-VTP4-M-00
1 / 2		REVISIONS
UNLESS OTHERWISE SPECIFIED		DATE
ALL DIMENSIONS ARE IN MILLIMETRES		09/11/2023
TOLERANCES		REVISION WEIGHT
LINEAR		0
ANGULAR		3.6 KG
OTHER THAN UP TO 0.1		REPLACES DRAWING
OTHER THAN UP TO 0.05		-
OTHER THAN UP TO 0.02		-
OTHER THAN UP TO 0.01		PROFILE NUMBER
OTHER THAN UP TO 0.005		-
ANGULAR ±0.5°		
SURFACE ROUGHNESS		
IF IN DOUBT ASK		

RRI-VTP4-M - 4 STATION PENDANT C/W EMERGENCY STOP VALVE (S406-MJV03-ASSY)



RRI-VTP4-M - 4 STATION PENDANT C/W EMERGENCY STOP VALVE (S406-MJV03-ASSY) - PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	RRI-VTP4-M-01	FRONT CASE
2	1	XAC402-02	RUBBER SEAL
3	1	XAC402-03	WASHER M4
4	6	XAC602-12	SLOTTED CHEESE HEAD SCREW M4X14
5	6	XAC602-13	WASHER M4
6	6	XAC602-14	PLASTIC WASHER M4
7	1	RRI-LABEL-ROOSTER	RED ROOSTER LABEL
8	1	RRI-LABEL-E-STOP	EMERGENCY STOP LABEL
9	1	E-STOP-GUARD01	YELLOW E-STOP GUARD
10	1	XAC-B-LEGEND-UP	UP LEGEND
11	1	XAC-B-LEGEND-DOWN	DOWN LEGEND
12	1	XAC-B-LEGEND-RIGHT	RIGHT LEGEND
13	1	XAC-B-LEGEND-LEFT	LEFT LEGEND
14	1	XAC-B-LEGEND-VALVE	BUTTON VALVE
15	4	BK-3209-JAL-VE	BUTTON COVER
16	4	BK-3209-292-B-COVER	Y- BRANCH
17	1	P080	1/8" BSP TO 6MM PUSH FIT
18	4	P087	SLOTTED CHEESE HEAD SCREW M4X20
19	2	P059	6MM DOUBLE Y- BRANCH
20	1	P114	6MM PLUG IN ELBOW
21	2	P118	HEX NYLOC NUT M4
22	2	P131-P	HEX NYLOC NUT M4
23	2	P131-P	HEX NYLOC NUT M4
24	2	P131-P	HEX NYLOC NUT M4
25	6	P131-P	HEX NYLOC NUT M4
26	12	UP7	1/8" BSP TO 6MM PUSH FIT
27	2	RRI-VTP4-M-02	EMERGENCY STOP VALVE AND BUTTON
28	2	ISO 4018 - M6 X 25	FLAT WASHER M6
29	2	P139-P	HEX NYLOC NUT M6
30	4	P45-P	HEX NYLOC NUT M6
31	6	P245	6MM TO 1/8" BSP BULKHEAD ADAPTOR
32	12	P071-H	1/8" BSP HEX NYPPLE C/W 60° CONE
33	6	P016-I	1/8" BSP TO 1/4" SWIVEL HOSE TAIL
34	6	I-4 HOSE	1/4" ANTI-STATIC 20BAR BLACK AIR HOSE (BS EN ISO 2398:2016)
35	12	P002-I	1/4" HOSE FERRULE (GALVANISED)
S406-MJV03-ASSY			
TITLE OF PART			
GENERAL ASSEMBLY			
DATE			
REVISION WEIGHT			
REPLACES DRAWING			
UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN MILLIMETERS			
TOLERANCES			
LINEAR			
OVER 30 TO 40 ±0.1			
OVER 40 TO 60 ±0.1			
OVER 60 TO 100 ±0.1			
OVER 100 TO 150 ±0.1			
OVER 150 TO 200 ±0.1			
OVER 200 TO 250 ±0.1			
OVER 250 TO 300 ±0.1			
OVER 300 TO 350 ±0.1			
OVER 350 TO 400 ±0.1			
OVER 400 TO 450 ±0.1			
OVER 450 TO 500 ±0.1			
OVER 500 TO 550 ±0.1			
OVER 550 TO 600 ±0.1			
OVER 600 TO 650 ±0.1			
OVER 650 TO 700 ±0.1			
OVER 700 TO 750 ±0.1			
OVER 750 TO 800 ±0.1			
OVER 800 TO 850 ±0.1			
OVER 850 TO 900 ±0.1			
OVER 900 TO 950 ±0.1			
OVER 950 TO 1000 ±0.1			
OVER 1000 TO 1050 ±0.1			
OVER 1050 TO 1100 ±0.1			
OVER 1100 TO 1150 ±0.1			
OVER 1150 TO 1200 ±0.1			
OVER 1200 TO 1250 ±0.1			
OVER 1250 TO 1300 ±0.1			
OVER 1300 TO 1350 ±0.1			
OVER 1350 TO 1400 ±0.1			
OVER 1400 TO 1450 ±0.1			
OVER 1450 TO 1500 ±0.1			
OVER 1500 TO 1550 ±0.1			
OVER 1550 TO 1600 ±0.1			
OVER 1600 TO 1650 ±0.1			
OVER 1650 TO 1700 ±0.1			
OVER 1700 TO 1750 ±0.1			
OVER 1750 TO 1800 ±0.1			
OVER 1800 TO 1850 ±0.1			
OVER 1850 TO 1900 ±0.1			
OVER 1900 TO 1950 ±0.1			
OVER 1950 TO 2000 ±0.1			
OVER 2000 TO 2050 ±0.1			
OVER 2050 TO 2100 ±0.1			
OVER 2100 TO 2150 ±0.1			
OVER 2150 TO 2200 ±0.1			
OVER 2200 TO 2250 ±0.1			
OVER 2250 TO 2300 ±0.1			
OVER 2300 TO 2350 ±0.1			
OVER 2350 TO 2400 ±0.1			
OVER 2400 TO 2450 ±0.1			
OVER 2450 TO 2500 ±0.1			
OVER 2500 TO 2550 ±0.1			
OVER 2550 TO 2600 ±0.1			
OVER 2600 TO 2650 ±0.1			
OVER 2650 TO 2700 ±0.1			
OVER 2700 TO 2750 ±0.1			
OVER 2750 TO 2800 ±0.1			
OVER 2800 TO 2850 ±0.1			
OVER 2850 TO 2900 ±0.1			
OVER 2900 TO 2950 ±0.1			
OVER 2950 TO 3000 ±0.1			
OVER 3000 TO 3050 ±0.1			
OVER 3050 TO 3100 ±0.1			
OVER 3100 TO 3150 ±0.1			
OVER 3150 TO 3200 ±0.1			
OVER 3200 TO 3250 ±0.1			
OVER 3250 TO 3300 ±0.1			
OVER 3300 TO 3350 ±0.1			
OVER 3350 TO 3400 ±0.1			
OVER 3400 TO 3450 ±0.1			
OVER 3450 TO 3500 ±0.1			
OVER 3500 TO 3550 ±0.1			
OVER 3550 TO 3600 ±0.1			
OVER 3600 TO 3650 ±0.1			
OVER 3650 TO 3700 ±0.1			
OVER 3700 TO 3750 ±0.1			
OVER 3750 TO 3800 ±0.1			
OVER 3800 TO 3850 ±0.1			
OVER 3850 TO 3900 ±0.1			
OVER 3900 TO 3950 ±0.1			
OVER 3950 TO 4000 ±0.1			
OVER 4000 TO 4050 ±0.1			
OVER 4050 TO 4100 ±0.1			
OVER 4100 TO 4150 ±0.1			
OVER 4150 TO 4200 ±0.1			
OVER 4200 TO 4250 ±0.1			
OVER 4250 TO 4300 ±0.1			
OVER 4300 TO 4350 ±0.1			
OVER 4350 TO 4400 ±0.1			
OVER 4400 TO 4450 ±0.1			
OVER 4450 TO 4500 ±0.1			
OVER 4500 TO 4550 ±0.1			
OVER 4550 TO 4600 ±0.1			
OVER 4600 TO 4650 ±0.1			
OVER 4650 TO 4700 ±0.1			
OVER 4700 TO 4750 ±0.1			
OVER 4750 TO 4800 ±0.1			
OVER 4800 TO 4850 ±0.1			
OVER 4850 TO 4900 ±0.1			
OVER 4900 TO 4950 ±0.1			
OVER 4950 TO 5000 ±0.1			
OVER 5000 TO 5050 ±0.1			
OVER 5050 TO 5100 ±0.1			
OVER 5100 TO 5150 ±0.1			
OVER 5150 TO 5200 ±0.1			
OVER 5200 TO 5250 ±0.1			
OVER 5250 TO 5300 ±0.1			
OVER 5300 TO 5350 ±0.1			
OVER 5350 TO 5400 ±0.1			
OVER 5400 TO 5450 ±0.1			
OVER 5450 TO 5500 ±0.1			
OVER 5500 TO 5550 ±0.1			
OVER 5550 TO 5600 ±0.1			
OVER 5600 TO 5650 ±0.1			
OVER 5650 TO 5700 ±0.1			
OVER 5700 TO 5750 ±0.1			
OVER 5750 TO 5800 ±0.1			
OVER 5800 TO 5850 ±0.1			
OVER 5850 TO 5900 ±0.1			
OVER 5900 TO 5950 ±0.1			
OVER 5950 TO 6000 ±0.1			
OVER 6000 TO 6050 ±0.1			
OVER 6050 TO 6100 ±0.1			
OVER 6100 TO 6150 ±0.1			
OVER 6150 TO 6200 ±0.1			
OVER 6200 TO 6250 ±0.1			
OVER 6250 TO 6300 ±0.1			
OVER 6300 TO 6350 ±0.1			
OVER 6350 TO 6400 ±0.1			
OVER 6400 TO 6450 ±0.1			
OVER 6450 TO 6500 ±0.1			
OVER 6500 TO 6550 ±0.1			
OVER 6550 TO 6600 ±0.1			
OVER 6600 TO 6650 ±0.1			
OVER 6650 TO 6700 ±0.1			
OVER 6700 TO 6750 ±0.1			
OVER 6750 TO 6800 ±0.1			
OVER 6800 TO 6850 ±0.1			
OVER 6850 TO 6900 ±0.1			
OVER 6900 TO 6950 ±0.1			
OVER 6950 TO 7000 ±0.1			
OVER 7000 TO 7050 ±0.1			
OVER 7050 TO 7100 ±0.1			
OVER 7100 TO 7150 ±0.1			
OVER 7150 TO 7200 ±0.1			
OVER 7200 TO 7250 ±0.1			
OVER 7250 TO 7300 ±0.1			
OVER 7300 TO 7350 ±0.1			
OVER 7350 TO 7400 ±0.1			
OVER 7400 TO 7450 ±0.1			
OVER 7450 TO 7500 ±0.1			
OVER 7500 TO 7550 ±0.1			
OVER 7550 TO 7600 ±0.1			
OVER 7600 TO 7650 ±0.1			
OVER 7650 TO 7700 ±0.1			
OVER 7700 TO 7750 ±0.1			
OVER 7750 TO 7800 ±0.1			
OVER 7800 TO 7850 ±0.1			
OVER 7850 TO 7900 ±0.1			
OVER 7900 TO 7950 ±0.1			
OVER 7950 TO 8000 ±0.1			
OVER 8000 TO 8050 ±0.1			
OVER 8050 TO 8100 ±0.1			
OVER 8100 TO 8150 ±0.1			
OVER 8150 TO 8200 ±0.1			
OVER 8200 TO 8250 ±0.1			
OVER 8250 TO 8300 ±0.1			
OVER 8300 TO 8350 ±0.1			
OVER 8350 TO 8400 ±0.1			
OVER 8400 TO 8450 ±0.1			
OVER 8450 TO 8500 ±0.1			
OVER 8500 TO 8550 ±0.1			
OVER 8550 TO 8600 ±0.1			
OVER 8600 TO 8650 ±0.1			
OVER 8650 TO 8700 ±0.1			
OVER 8700 TO 8750 ±0.1			
OVER 8750 TO 8800 ±0.1			
OVER 8800 TO 8850 ±0.1			
OVER 8850 TO 8900 ±0.1			
OVER 8900 TO 8950 ±0.1			
OVER 8950 TO 9000 ±0.1			
OVER 9000 TO 9050 ±0.1			
OVER 9050 TO 9100 ±0.1			
OVER 9100 TO 9150 ±0.1			
OVER 9150 TO 9200 ±0.1			
OVER 9200 TO 9250 ±0.1			
OVER 9250 TO 9300 ±0.1			
OVER 9300 TO 9350 ±0.1			
OVER 9350 TO 9400 ±0.1			
OVER 9400 TO 9450 ±0.1			
OVER 9450 TO 9500 ±0.1			
OVER 9500 TO 9550 ±0.1			
OVER 9550 TO 9600 ±0.1			
OVER 9600 TO 9650 ±0.1			
OVER 9650 TO 9700 ±0.1			
OVER 9700 TO 9750 ±0.1			
OVER 9750 TO 9800 ±0.1			
OVER 9800 TO 9850 ±0.1			
OVER 9850 TO 9900 ±0.1			
OVER 9900 TO 9950 ±0.1			
OVER 9950 TO 10000 ±0.1			
OVER 10000 TO 10050 ±0.1			
OVER 10050 TO 10100 ±0.1			
OVER 10100 TO 10150 ±0.1			
OVER 10150 TO 10200 ±0.1			
OVER 10200 TO 10250 ±0.1			
OVER 10250 TO 10300 ±0.1			
OVER 10300 TO 10350 ±0.1			
OVER 10350 TO 10400 ±0.1			
OVER 10400 TO 10450 ±0.1			
OVER 10450 TO 10500 ±0.1			
OVER 10500 TO 10550 ±0.1			
OVER 10550 TO 10600 ±0.1			
OVER 10600 TO 10650 ±0.1			
OVER 10650 TO 10700 ±0.1			
OVER 10700 TO 10750 ±0.1			
OVER 10750 TO 10800 ±0.1			
OVER 10800 TO 10850 ±0.1			
OVER 10850 TO 10900 ±0.1			
OVER 10900 TO 10950 ±0.1			
OVER 10950 TO 11000 ±0.1			
OVER 11000 TO 11050 ±0.1			
OVER 11050 TO 11100 ±0.1			
OVER 11100 TO 11150 ±0.1			
OVER 11150 TO 11200 ±0.1			
OVER 11200 TO 11250 ±0.1			
OVER 11250 TO 11300 ±0.1			
OVER 11300 TO 11350 ±0.1			
OVER 11350 TO 11400 ±0.1			
OVER 11400 TO 11450 ±0.1			
OVER 11450 TO 11500 ±0.1			
OVER 11500 TO 11550 ±0.1			
OVER 11550 TO 11600 ±0.1			
OVER 11600 TO 11650 ±0.1			
OVER 11650 TO 11700 ±0.1			
OVER 11700 TO 11750 ±0.1			
OVER 11750 TO 11800 ±0.1			
OVER 11800 TO 11850 ±0.1			
OVER 11850 TO 11900 ±0.1			
OVER 11900 TO 11950 ±0.1			
OVER 11950 TO 12000 ±0.1			
OVER 12000 TO 12050 ±0.1			
OVER 12050 TO 12100 ±0.1			
OVER 12100 TO 12150 ±0.1			
OVER 12150 TO 12200 ±0.1			
OVER 12200 TO 12250 ±0.1			
OVER 12250 TO 12300 ±0.1			
OVER 12300 TO 12350 ±0.1			
OVER 12350 TO 12400 ±0.1			
OVER 12400 TO 12450 ±0.1			
OVER 12450 TO 12500 ±0.1			
OVER 12500 TO 12550 ±0.1			
OVER 12550 TO 12600 ±0.1			
OVER 12600 TO 12650 ±0.1			
OVER 12650 TO 12700 ±0.1			
OVER 12700 TO 12750 ±0.1			
OVER 12750 TO 12800 ±0.1			
OVER 12800 TO 12850 ±0.1			
OVER 12850 TO 12900 ±0.1			
OVER 12900 TO 12950 ±0.1			
OVER 12950 TO 13000 ±0.1			
OVER 13000 TO 13050 ±0.1			
OVER 13050 TO 13100 ±0.1			
OVER 13100 TO 13150 ±0.1			
OVER 13150 TO 13200 ±0.1			
OVER 13200 TO 13250 ±0.1			
OVER 13250 TO 13300 ±0.1			
OVER 13300 TO 13350 ±0.1			
OVER 13350 TO 13400 ±0.1			
OVER 13400 TO 13450 ±0.1			
OVER 13450 TO 13500 ±0.1			
OVER 13500 TO 13550 ±0.1			
OVER 13550 TO 13600 ±0.1			
OVER 13600 TO 13650 ±0.1			
OVER 13650 TO 13700 ±0.1			
OVER 13700 TO 13750 ±0.1			
OVER 13750 TO 13800 ±0.1			
OVER 13800 TO 13850 ±0.1			
OVER 13850 TO 13900 ±0.1			
OVER 13900 TO 13950 ±0.1			
OVER 13950 TO 14000 ±0.1			
OVER 14000 TO 14050 ±0.1			
OVER 14050 TO 14100 ±0.1			
OVER 14100 TO 14150 ±0.1			
OVER 14150 TO 14200 ±0.1			
OVER 14200 TO 14250 ±0.1			
OVER 14250 TO 14300 ±0.1			
OVER 14300 TO 14350 ±0.1			
OVER 14350 TO 14400 ±0.1			
OVER 14400 TO 14450 ±0.1			
OVER 14450 TO 14500 ±0.1			
OVER 14500 TO 14550 ±0.1			
OVER 14550 TO 14600 ±0.1			
OVER 14600 TO 14650 ±0.1			
OVER 14650 TO 14700 ±0.1			
OVER 14700 TO 14750 ±0.1			
OVER 14750 TO 14800 ±0.1			
OVER 14800 TO 14850 ±0.1			
OVER 14850 TO 14900 ±0.1			
OVER 14900 TO 14950 ±0.1			
OVER 14950 TO 15000 ±0.1			
OVER 15000 TO 15050 ±0.1			
OVER 15050 TO 15100 ±0.1			
OVER 15100 TO 15150 ±0.1			
OVER 15150 TO 15200 ±0.1			
OVER 15200 TO 15250 ±0.1			
OVER 15250 TO 15300 ±0.1			
OVER 15300 TO 15350 ±0.1			
OVER 15350 TO 15400 ±0.1			
OVER 15400 TO 15450 ±0.1			
OVER 15450 TO 15500 ±0.1			
OVER 15500 TO 15550 ±0.1			
OVER 15550 TO 15600 ±0.1			
OVER 15600 TO 15650 ±0.1			
OVER 15650 TO 15700 ±0.1			
OVER 15700 TO 15750 ±0.1			
OVER 15750 TO 15800 ±0.1			
OVER 15800 TO 15850 ±0.1			
OVER 15850 TO 15900 ±0.1			
OVER 15900 TO 15950 ±0.1			
OVER 15950 TO 16000 ±0.1			
OVER 16000 TO 16050 ±0.1			
OVER 16050 TO 16100 ±0.1			
OVER 16100 TO 16150 ±0.1			
OVER 16150 TO 16200 ±0.1			
OVER 16200 TO 16250 ±0.1			
OVER 16250 TO 16300 ±0.1			
OVER 16300 TO 16350 ±0.1			
OVER 16350 TO 16400 ±0.1			
OVER 16400 TO 16450 ±0.1			
OVER 16450 TO 16500 ±0.1			
OVER 16500 TO 16550 ±0.1			
OVER 16550 TO 16600 ±0.1			
OVER 16600 TO 16650 ±0.1			
OVER 16650 TO 16700 ±0.1			
OVER 16700 TO 16750 ±0.1			
OVER 16750 TO 16800 ±0.1			
OVER 16800 TO 16850 ±0.1			
OVER 16850 TO 16900 ±0.1			
OVER 16900 TO 16950 ±0.1			
OVER 16950 TO 17000 ±0.1			
OVER 17000 TO 17050 ±0.1			
OVER 17050 TO 17100 ±0.1			
OVER 17100 TO 17150 ±0.1			
OVER 17150 TO 17200 ±0.1			
OVER 17200 TO 17250 ±0.1			
OVER 17250 TO 17300 ±0.1			
OVER 17300 TO 17350 ±0.1			
OVER 17350 TO 17400 ±0.1			
OVER 17400 TO 17450 ±0.1			
OVER 17450 TO 17500 ±0.1			
OVER 17500 TO 17550 ±0.1			
OVER 17550 TO 17600 ±0.1			
OVER 17600 TO 17650 ±0.1			
OVER 17650 TO 17700 ±0.1			
OVER 17700 TO 17750 ±0.1			
OVER 17750 TO 17800 ±0.1			
OVER 17800 TO 17850 ±0.1			
OVER 17850 TO 17900 ±0.1			
OVER 17900 TO 17950 ±0.1			
OVER 17950 TO 18000 ±0.1			
OVER 18000 TO 18050 ±0.1			
OVER 18050 TO 18100 ±0.1			
OVER 18100 TO 18150 ±0.1			
OVER 18150 TO 18200 ±0.1			
OVER 18200 TO 18250 ±0.1			
OVER 18250 TO 18300 ±0.1			
OVER 18300 TO 18350 ±0.1			
OVER 18350 TO 18400 ±0.1			
OVER 18400 TO 18450 ±0.1			
OVER 18450 TO 18500 ±0.1			
OVER 18500 TO 18550 ±0.1			

REVISION HISTORY		
REV.	DATE	APPROVED
0	21/03/2024	PAUL SHEWAN



VRD-4R STATION PENDANT - STANDARD VERSION - PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	420235W50	FRONT CASE
2	1	420235W60	REAR CASE
3	1	136608256	BOOT
4	4	420235X40	BUTTON
5	1	420235V60	VALVE BODY
6	1	136690503	EMERGENCY STOP BUTTON
7	2	13103004	O-RING S-6
8	1	420228W00	PUSH ROD
9	1	420224V61	EMERGENCY STOP VALVE
10	2	13103002	O-RING S-4
11	1	420228V60	EMERGENCY STOP BUSHING
12	6	13103009	O-RING S-II,2
13	5	13103008	RETAINING RING E-4
14	1	131030204	HEX SOCKET HEAD CAP SCREW M5X10
15	1	131705370	WASHER M5
16	1	131092005	RETAINING RING H-12
17	1	130301912	WASHER M6
18	1	131092006	O-RING S-7
19	1	13103005	ADJUST SCREW
20	1	420235V60	THROTTLE VALVE
21	4	420218V60	SPRING 6X18X0.32
22	4	130802036	BUSHING
23	4	420218V-0	O-RING S-3 (HS90)
24	4	13109001	HEX SOCKET SET SCREW M5X5
25	4	132005305	PHILLIPS PAN HEAD MACHINE SCREW M5X14
26	4	132404114	PHILLIPS PAN HEAD SELF-TAPPING SCREW 4X20
27	6	132904221	1/4" HOSE FERRULE (GALVANIZED)
28	12	P002-I	1/8" BSP TO 1/4" SWIVEL HOSETAIL
29	12	P016-I	1/8" BSP HEX NIPPLE C/W 60° CONE
30	6	P07-I	1/8" BSP COMPACT ELBOW C/W 60° CONE
31	4	P128	1/4" ANTI-STATIC 20BAR BLACK AIR HOSE (BS EN ISO 2398:2016)
32	6	1-4, HOSE	
SCALE		MATERIAL	
NTS		(SEE EXPLANATION)	
DESIGNED BY:	SURNAME DATE SIGNATURE		
	R. THURER 05/09/2023 <i>R. Thurer</i>		
DRAWN BY:	R. THURER 11/09/2023 <i>R. Thurer</i>		
CHECKED BY:	T. MYKOLA-SIEWNIK 12/10/2023 <i>T. Mykola-Siewnik</i>		
APPROVED BY:	P. SIEWNIK 13/10/2023 <i>P. Siewnik</i>		
SHEET SIZE:	TITLE OF PROJECT		
A3	VRD-4R STATION PENDANT		

VRD-4R-00
1 / 2

UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONS ARE IN MILLIMETERS
TOLERANCES
FRACTIONS TO 0.01
OVER 0.01 TO 0.05
OVER 0.05 TO 0.10
OVER 0.10 TO 0.25
OVER 0.25 TO 0.50
OVER 0.50 TO 1.00
OVER 1.00 TO 2.00
ANGULAR 4.0/5°
SURFACE ROUGHNESS RY
IF IN DOUBT ASK

DATE 11/09/2023

REVISION WEIGHT 0 2.8 KG

REPLACES DRAWING -


PROFILE NUMBER -

RED ROOSTER
LIFTING

ALUMINIUM MADE IN THE NETHERLANDS
TEL: +31 (0)6 4300 8888
WWW.ALUMINIUM-ROOSTER.COM

The technical drawing consists of two views of the LED light fixture:

- Top View (Side Profile):** Shows the length of the fixture as approximately 101 (~101). It details the mounting bracket at one end, the main body with cooling fins, and the multi-lens head.
- Bottom View (Front View):** Shows the width of the fixture as approximately 86 (~86) and the depth of the main body as approximately 326 (~326). This view clearly shows five individual LED chips arranged horizontally within the lens assembly. A label "LED chip" points to one of the chips.




VRD-4R STATION PENDANT - 4 TEX VERSION - PARTS LIST				REV.
ITEM	QTY	PART NUMBER	DESCRIPTION	
4	4	420235X40	BUTTON	
5	1	420235X40	VALVE BODY	
6	1	136090503	EMERGENCY STOP BUTTON	
7	2	131033004	O-RING S-6	
8	1	420235X60	PUSH ROD	
9	1	420235X60	EMERGENCY STOP VALVE	
10	1	420235X60	SPRING S-7	
11	2	420235X60	EMERGENCY STOP BUSHING	
12	6	131033009	O-RING S-11/2	
13	5	131033008	O-RING S-10	
14	1	1303033024	RETAINING RING E-4	
15	1	1317065310	HEX SOCKET HEAD CAP SCREW M5x10	
16	1	1315092025	WASHER M5	
17	1	130301912	RETAINING RING H-1/2	
18	1	131509206	WASHER M6	
19	1	131033005	O-RING S-7	
20	1	420235X60	ADJUST SCREW	
21	4	420218180	THROTTLE VALVE	
22	4	130802036	SPRING 6X18X0.32	
23	4	4202181F-0	BUSHING	
24	4	131080001	O-RING S-3 (HS90)	
25	4	132083305	HEX SOCKET SET SCREW M5X5	
26	4	132040414	PHILLIPS PAN HEAD MACHINE SCREW M5 X4	
27	6	132904221	PHILLIPS PAN HEAD SELF-TAPPING SCREW 4X20	
28	12	P002-1	1/4" HOSE FERRULE (GALVANISED)	
29	12	P018-1	1/8" HOSE FERRULE (GALVANISED)	
30	6	P071-1	1/8" BSP TO 1/4" SWIVEL HOSE TAIL	
31	4	P128	1/8" BSP HEX NIPPLE C/W 60° CONE	
32	6	14- HOSE	1/8" BSP COMPACT ELBOW C/W 60° CONE	
33	1	420235X50	1/4" ANTI-STATIC ZUBAR BLACK AIR HOSE (BS EN ISO 2398:2016)	
34	1	420235X60	FRONT CASE	
35	1	136000261	REAR CASE	
36	1	131033016	BOOT S	
37	4	16207105	YELLOW STICKER	
38	4	16207106	WASHER M5	

SCALE		MATERIAL	TITLE OF PART	PART NUMBER	
NTS			GENERAL ASSEMBLY	VRD-4R-00 2 / 2	
DESIGNED BY	SURNAME	DATE	SIGNATURE	DATE	
DRAWN BY	R. THORER	05/09/2023	<i>R. Thor</i>	11/09/2023	
CHECKED BY	R. THORER	11/09/2023	<i>R. Thor</i>	REVISION	WEIGHT
APPROVED BY	T. MICALLEWISKI	12/10/2023	<i>T. Mical</i>	0	2.8 KG
SHEET SIZE	P. SHERMAN	13/10/2023	<i>P. Sher</i>	REPLACES DRAWING	
				PROFILE NUMBER	

RED ROOSTER LIFTING		TITLE OF PROJECT	
VRD-4R STATION PENDANT			
 RED ROOSTER LIFTING MADE IN POLAND. THE ROOSTER IS A TRADE MARK OF RED ROOSTER LIFTING. THE ROOSTER IS A TRADE MARK OF RED ROOSTER LIFTING.		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN MILLIMETERS LINEAR UP TO 5 ±0.05 5 TO 10 ±0.1 10 TO 20 ±0.15 20 TO 30 ±0.2 30 TO 50 ±0.25 50 TO 100 ±0.3 ANGULAR 4.0 ±0.5 IF IN DOUBT ASK	


CHAIN COLLECTOR 400X400

REVISION HISTORY		
REV.	DATE	APPROVED
0	09/08/2024	PAUL SHEWAN



CHAIN COLLECTOR 400X400 - PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	TMH-10-BB-00	BUCKET BRACKET
2	1	CHAIN COLLECTOR 400X400	CHAIN COLLECTOR
3	1	RRL 1598-CC-07	FRONT HANGER BRACKET - TWISTED
4	14	DIN 125 - A 13	WASHER
5	4	ISO 4017 - M12 X 30	HEX-HEAD BOLT
6	6	DIN 985 - M12	HEX NUT
7	2	ISO 4017 - M12 X 50	HEX-HEAD BOLT
8	2	ISO 4032 - M12	HEX NUT - PRODUCT GRADES A AND B
SCALE		TITLE OF PART	
NTS		CHAIN COLLECTOR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
APPROVED BY		DATE	
P. SHEWAN		28/06/2024	
SHEET SIZE		TITLE OF PROJECT	
A3		TMH20 - 20T 4F LHR	
DESIGNED BY		DATE	
T. MICALLENSKI		16/06/2023	
DRAWN BY		DATE	
T. MICALLENSKI		25/06/2024	
CHECKED BY		DATE	
P. SHEWAN		27/06/2024	
AP			

CHAIN COLLECTOR 400x500




CHAIN COLLECTOR 400x500 - PARTS LIST				
ITEM	QTY	PART NUMBER	DESCRIPTION	REV.
1	1	TMH-10-BB-00	BUCKET BRACKET	1
3	1	RRL 1588-CC-07	FRONT BRACKET - TWISTED	0
4	22	DIN 125 - A 13	WASHER	
5	4	ISO 4017 - M12 X 30	HEX-HEAD BOLT	
6	10	DIN 985 - M12	HEX NUT	
7	2	ISO 4017 - M12 X 50	HEX-HEAD BOLT	
8	2	ISO 4032 - M12	HEX NUT, PRODUCT GRADES A AND B	
9	4	ISO 4017 - M12 X 35	HEX-HEAD BOLT	
10	1	RRL 1588-CC-01	BUCKET EXTENSION BRACKET (400x500)	0
11	1	CHAIN COLLECTOR 400x500	CHAIN COLLECTOR	0
TITLE OF PART				
MATERIAL (if applicable)				
SCALE				
PART NUMBER				
RRL 1597-CC				
2 / 4				
UNLESS OTHERWISE SPECIFIED				
ALL DIMENSIONS ARE IN MILLIMETERS				
TOLERANCES				
LINEAR				
UP TO 300 ±0,05				
OVER 300 UP TO 1000 ±0,1				
OVER 1000 ±0,15				
ANGULAR ±0,5°				
SURFACE ROUGHNESS Ra				
IF IN DOUBT ASK				

DATE		25/06/2024	
REVISION WEIGHT		0 / 131,9 KG	
REPLACES DRAWING		-	
PROFILE NUMBER		-	

	
RED ROOSTER	
LIFTING	
WARTA WIELKA, THE NATIONAL CRANES MANUFACTURING AND REPAIRING ENTERPRISE, 01-651 WARSZAWA, POLSKA	
WWW.ROOSTERLIFT.COM	



TMH20 - 20T 4F LHR	
	
A3	

CHAIN COLLECTOR 500x500



CHAIN COLLECTOR 500x500 - PARTS LIST									
ITEM	QTY	PART NUMBER	DESCRIPTION	REV.					
1	1	TMH-10-BB-00	BUCKET BRACKET	1					
3	1	RRL 1588-CC-07	FRONT HANGER BRACKET - TWISTED	0					
4	22	DIN 125 - A 13	WASHER						
5	4	ISO 4017 - M12 x 30	HEX-HEAD BOLT						
6	10	DIN 985 - M12	HEX NUT						
7	2	ISO 4017 - M12 x 50	HEX-HEAD BOLT						
8	2	ISO 4032 - M12	HEX NUT, PRODUCT GRADES A AND B						
9	4	ISO 4017 - M12 x 35	HEX-HEAD BOLT						
12	1	RRL 1588-CC-02	BUCKET EXTENSION BRACKET (500x500)	0					
13	1	CHAIN COLLECTOR 500x500	CHAIN COLLECTOR	0					
SCALE		TITLE OF PART		PART NUMBER					
NTS		CHAIN COLLECTOR		RRL 1597-CC 3 / 4					
DESIGNED BY		DATE		UNLESS OTHERWISE SPECIFIED					
DRAWN BY		25/06/2024		ALL DIMENSIONS ARE IN MILLIMETERS					
CHECKED BY		REVISION WEIGHT		TOLERANCES					
APPROVED BY		0 131.9 KG		LINEAR					
SHEET SIZE		REPLACES DRAWING		UP TO 3 ±0,05					
A3		-		OVER 30 UP TO 100 ±0,1					
		-		OVER 100 UP TO 300 ±0,2					
		-		OVER 300 UP TO 1000 ±0,5					
		-		OTHER SURFACES TO 1000 ±0,6					
		-		ANGULAR ±0,5°					
		-		SURFACE ROUGHNESS Ra					
		-		IF IN DOUBT ASK					


CHAIN COLLECTOR 600X600



CHAIN COLLECTOR 600X600 - PARTS LIST									
ITEM	QTY	PART NUMBER	DESCRIPTION	REV.					
1	1	TMH-10-BB-00	BUCKET BRACKET	1					
3	1	RRL 1588-CC-03	FRONT BRACKET - TWISTED	0					
4	22	DIN 125 - A 13	WASHER						
5	4	ISO 4017 - M12 x 30	HEX-HEAD BOLT						
6	10	DIN 985 - M12	HEX NUT						
7	2	ISO 4017 - M12 x 50	HEX-HEAD BOLT						
8	2	ISO 4032 - M12	HEX NUT, PRODUCT GRADES A AND B						
9	4	ISO 4017 - M12 x 35	HEX-HEAD BOLT						
14	1	RRL 1588-CC-03	BUCKET EXTENSION BRACKET (600X600)	0					
15	1	CHAIN COLLECTOR 600X600	CHAIN COLLECTOR	0					
SCALE		TITLE OF PART		PART NUMBER					
NTS		CHAIN COLLECTOR		RRL 1597-CC					
DESIGNED BY		DATE		4 / 4					
T. MICOLA (REVISED)		16/06/2023		UNLESS OTHERWISE SPECIFIED					
DRAWN BY		25/06/2024		ALL DIMENSIONS ARE IN MILLIMETERS					
T. MICOLA (REVISED)		25/06/2024		TOLERANCES					
CHECKED BY		27/06/2024		LINEAR					
P. SHERMAN		27/06/2024		UP TO ±0,1					
APPROVED BY		28/06/2024		OTHER: ±0,05					
P. SHERMAN		28/06/2024		OTHER: ±0,02					
SHEET SIZE		TITLE OF PROJECT		OTHER: ±0,01					
A3		TMH20 - 20T 4F LHR		ANGULAR ±0,5°					
				SURFACE ROUGHNESS					
				IF IN DOUBT ASK					

AIR MOTOR GLOBE VS6C

PARTS LIST			
ITEM	QTY	NAME	DESCRIPTION
1	1	BODY	
2	1	ROTOR SHAFT ASSY	
3	1	END PLATE	
4	1	FRONT PLATE D80	
5	1	COVER PLATE	
6	1	GASKET I	
7	1	GASKET II	
8	1	GASKET III	
9	1	SEAL HOUSING	
10	2	EJECTION RING	
11	4	BLADE	
12	1	SKF 2Z6203-2Z	DEEP GROOVE BALL BEARINGS SINGLE ROW WITH TWO Z SHIELDS SKF
13	1	DIN 472 - 40x1.75	RETAINING RINGS FOR BORES
14	3	ISO 4018 - M5 x 12	HEX-HEAD BOLT
15	4	ISO 2338 - 5 H8 x 16 - B	PARALLEL PIN
16	6	DIN 912 - M6 x 20	CYLINDER HEAD CAP SCREW
17	6	DIN 912 - M6 x 16	CYLINDER HEAD CAP SCREW
18	1	SKF 2Z3205 A-2Z	ANGULAR CONTACT BALL BEARINGS DOUBLE ROW WITH SHIELDS SKF
19	1	ISO 3601-I - B 0475 G	FLUID POWER SYSTEMS - O-RING
20	1	DIN 3760 - A - 25 x 35 x 7	SHAFT SEAL RING
21	3	DIN 7991 - M5x12	HEXAGON SOCKET COUNTERSUNK HEAD CAP SCREWS
22	1	DIN 6885 - A 6 x 6 x 28	PARALLEL KEY



4

WAY VALVES 5/2 and 5/3

Four-Way Valves are generally used to control double acting cylinders. They function to alternately direct pressure to one of two outlets at the same time exhausting pressure from the opposite outlet.



NOMINAL PRESSURE RANGE

Series "V": partial vacuum to 200 psi (14 bar)
pneumatic Series "T": 0-500 psi (35 bar) hydraulic

ACTUATION

MANUAL, MECHANICAL, PILOT
 or **SOLENOID-PILOT**

BODY TYPES: All Series "V" & "T" Four-Way Valves are available in the two body types described below. Actuators used with either body type are completely interchangeable.

HOW TO SELECT A VERSA VALVE

Every letter and digit in the product number has a significant meaning. The product number shown below (VJJ-4503) indicates the following

V	J	J	-	4	5	0	3
VALVE SERIES	ACTUATING DEVICES			FUNCTIONAL TYPE OF VALVE	VALVE PORT SIZE	BODY DETAILS	SPOOL DETAILS (FLOW PATTERNS)
	ON LEFT END OF VALVE LOOKING AT INLET	ON RIGHT END OF VALVE LOOKING AT INLET					
V Series "V" Valve Pneumatic service to 200 psi (14 bar)	J Pilot Spring Centreing (for 3 position pilot operated valves)	J Pilot Spring Centreing (for 3 position pilot operated valves)		4 Four-Way	*5 1/2" NPT *6 3/4" NPT *7 1" NPT *Basic valve size	0 SIDEPORTED-EXPILOT Body with integral, pipe threaded ports. This type of body is directly connected to pressure lines and is used for mechanical, manual nad EXPilot* type solenoid or pilot actuated valves.	THREE-WAY VALVES 3 Three Position All ports blocked in centre position.

PILOT

The pilot actuator is a small cylinder and piston that is an integral part of the valve and which, when pressurized or unpressurized, actuates the valve.

TYPE "P" PRESSURE PILOT (for 2-position valves)

60

TYPE "J" PRESSURE PILOT (for 3-position valves)

61

This pilot requires pressure to actuate the valve, and release of the pressure to return the valve. Usually it is controlled by a small Three-Way valve. The pilot port on the 1/4" through 1/2" valves may be rotated to any position in 90° increments from vertical. (See option arrangements below).


When used in pairs for 2-position valves, it is not necessary to maintain pressure on the actuated pilot in order for the valve to remain in actuated position. Valve will remain in last position until signalled by the opposite pilot to return. When used with spring centering feature ("J"), valve will remain in center position until actuated by either pilot. To remain in actuated position, pilot must remain pressurized until it is required for valve to return to center position.



60

61

**STANDARD
POSITION OF
PILOT INLET**





OPTIONS

Pilot actuated valves (1/4" thru 1/2") are supplied with the pilot port facing the same direction as the inlet port of the valve proper. Three other positions are available (Suffix-227A thru -227C). To order simply include the suffix number shown.



Example: VSP-4302-227A.

PILOT ACTUATED VALVES DIMENSIONS

SINGLE PILOT



DOUBLE PILOT



SIZE	A		B		B*		C		C*		D1		D		E		F		G	
	In	mm	In	mm	In	mm	In	mm	In	mm	In	mm	In	mm	In	mm	In	mm	In	mm
1/8-1/4	3.5	89	1.22	31	2.13	54	0.84	21	1.73	44	2.19	56	2	51	1	25	1.5	38	0.81	21
3/8-1/2	5.75	146	1.22	31	2.13	54	0.84	21	1.73	44	2.69	66	2.75	70	1.36	35	1.69	43	0.66	22
3/4-1-1 1/4†	8.5	216	2.06	52	3.53	90	—	—	—	—	—	—	3.75	95	1.88	48	2.44	62	1.25	32


*Dimensions for Spring-Centering Valves



HOW TO SELECT A VERSA VALVE

Every letter and digit in the product number has a significant meaning. The product number VPA3165-10 shown below shows the following:

VPA3	1	6	5	-	10
VALVE SERIES	PILOT №	BODY SIZE	BODY TYPE		PORT SIZE
Air Operated Valve Pneumatic Pilot Spring Centreing	Single	1	Body Ported		10 1"




Specifications

Fluid	Air	
Type of actuation	N.C. only (N.O. only for vacuum)	
Operating pressure range	For vacuum and low pressure	For ordinary pressure
	-101.2 kPa to 0.2 MPa	0.2 to 0.8 MPa
Pilot pressure range	Refer to the graph of pilot pressure.	
Ambient and fluid temperature (°C)	0 (No freezing) to 60	
Lubrication	Required (Turbine oil, Class 1 ISO VG32 equivalent)	
Mounting orientation	Free	
Impact/Vibration resistance (m/s ²) ^{Note)}	150/50	

Note) Impact resistance: No malfunction from test using drop impact tester, to axis and right angle directions of main valve, each one time when pilot signal ON and OFF. (Value in the initial stage)

Vibration resistance: No malfunction from test with 45 to 1000 Hz one sweep, to axis and right angle direction of main valve, each one time when pilot signal ON and OFF. (Value in the initial stage)

DIMENSIONS - VPA3165-10



MODEL	PORT SIZE		A	B	C	D	E	F	G	H	J	K	L	MOUNTING HOLE
	IN/OUT	EXH												
VPA3165-10	1"	1 1/4	82.6	110	17	68	75	118	45	113	36	71	95	Ø8.5


HOW TO SELECT A VERSA VALVE

Every letter and digit in the product number has a significant meaning. The product number VSP-3701-2B shown below shows the following:

V	S	P	-	3	7	0	1
VALVE SERIES	ACTUATING DEVICES			TYPE OF VALVE	VALVE PORT	BODY DETAILS	SPOOL DETAILS
	ON LEFT END OF VALVE LOOKING AT INLET	ON RIGHT END OF VALVE LOOKING AT INLET					
V Series "V" Valve Pneumatic service to 200 psi (14 bar)	S SPRING RETURN Spring pushes valve spool	P PRESSURE PILOT Two position		3 THREE-WAY	7 1" NPT	0 SIDEPORTED-EXPILOT Body with integral, pipe threaded ports. This type of body is directly connected to pressure lines and is used for mechanical, manual nad EXPIlot" type solenoid or pilot actuated valves.	1 Normally Closed

Valve model to suit: TNC10TWLPE, TNC-15TW/3, TNC-20TW/4, TNC-25TW, TNC-37.5TW, TNC-50TW/4

DIMENSIONS - VSP-3701





ACCESSORIES



ACCESSORIES

MAINS EMERGENCY STOP VALVES

ON TMH model hoists the mains valve can either be internal or mounted external to the hoist. As a mains emergency stop valve we use a range of 3/2 normally closed valves on pendant control hoists. These range from 1" to 1.5" depending on the hoist capacity.

Valve models: 1" = VPA 3165-10

UK Ex / ATEX version: 1" = VJJ4703-2B

DUMP VALVES

On hoists fitted with 1/4" air hose in place of tubes, dump valves are fitted to the control lines to reduce operating delays.

Valve model: DV/0.25

FILTER SILENCING - TYPE AMC


This ensures clean plant air and reduces noise levels.

In areas where you do not want the exhaust air / oil to go freely into the atmosphere we can either pipe the exhaust air away to another room, fit a filter silencer unit, or a combination of both using the exhaust pipe with a filter silencer on the end of the hose.


- ▷ The filter removes 99.9% of oil from the exhaust air.
- ▷ The noise level is also reduced by the silencer and also with the exhaust noise.
- ▷ Temperature range 5°C to 60°C.
- ▷ The exhaust hose and filter should be at least one size larger than the incoming air supply hose.
- ▷ The exhaust cleaner must be mounted vertically.
- ▷ If the oil drop level decreases or after a period of 1 year the filter element.

AMC

Construction/Dimensions




Model	Port size	A	B	C	D	Mounting bracket							Drain piping
						E	F	G	H	J	K	B'	
AMC310	3/8	150.5	138.5	140.5	75	M3 Depth	24	50	15	55	2.3	141.5	
AMC510	3/4	203.5	196.5	193.5	102	M4 Depth	40	70	20	70	3.2	199.5	
AMC610	1	229.5	224.5	219.5	118	M4 Depth	48	70	20	80	3.2	227.5	
AMC810	1 1/2	—	270	—	135	—	—	—	—	—	—	273	
AMC910	2	—	327	—	153	—	—	—	—	—	—	330	



Model	Port size	A	B	C	D	Mounting bracket							Drain piping
						E	F	G	H	J	K	L	
AMC220	1/4	100	88	56	M3 Depth	22	40	2.3	15	12	20	50	73"
AMC320	1/4, 3/8	140.5	120.5	75	M3 Depth	24	55	2.3	15	20	30	50	123.5
AMC520	1/2, 3/4	193.5	173.5	102	M4 Depth	40	70	3.2	20	20	30	70	176.5

* On the AMC220, an R(PT)1/4 fitting can be attached by removing the drain cock.

Flow Characteristics



How to view the diagram: If the AMC510 is operated at a flow volume of 1000 l/min (ANR), the supply pressure will be 0.05MPa.

⚠️ Precautions

Design

⚠️ Warning

- The exhaust port could become blocked by the clogging of the exhaust cleaner. Therefore, make sure to provide a safe design so as not to cause the whole system to malfunction.

⚠️ Caution

- If this will be used with a centralized piping system, calculate the **peak** maximum air consumption by including the actuators that operate simultaneously and the capacity of the piping that is connected. Then, select a model so that the calculated value will be less than the maximum flow volume of the **exhaust cleaner**. (Select a style with ample capacity because the exhaust speed will decrease when the **element** becomes clogged.)
- The silencing effect could vary depending on the pneumatic circuit or the pressure that is used.
- Operate at a back pressure (Supply pressure) of 0.1MPa or less.
- The attached bracket is for supporting the exhaust cleaner body. Thus, it cannot support the piping or other items. If these items need to be supported, provide an additional support.

Mounting


⚠️ Caution

- An exhaust cleaner must be mounted vertically. If it is mounted diagonally, laterally, or inverted, the oil that is separated by the element will splash on the surroundings.

Maintenance

⚠️ Caution

- If the exhaust speed drops and the system performance decreases due to clogging, replace with a new element. Make sure to verify the operating condition of the actuator at least once a day.
- The replacement interval for the element is before the internal pressure during exhaust reaches 0.1MPa or after 1 year of operation, whichever comes first.



- Provide a branch on the supply side of the exhaust cleaner to mount a valve and a pressure gauge.
- During inspection, open the valve and check the pressure at the time of exhaust discharge. (The **valve** must remain closed except for inspection. The pressure gauge could break if the valve remains open.)

AIR SERVICE EQUIPMENT

An air set should be used with all Red Rooster hoists and trolleys.

AIR SERVICE UNITS:

The correct size of air service unit for each hoist type is stated in the table on page 4. The air service unit must be installed with the lubricator unit down line from the filter unit. The unit should be installed at the hoist inlet port or within eight metres of inlet port. (Siting the unit further away or well below the hoist will result in lubricant being deposited on the internal walls of the supply line and hence it will be necessary to increase the lubricant rate above the levels specified (see section 1.2) to ensure adequate lubrication of the hoist. The ambient temperature range is -5°C to +60°C (with no freezing).

FILTER UNIT (WATER TRAP)

Manual drain units

As the name implies, these units must be drained by the operator as the filter bowl becomes full of water. The frequency of draining is entirely dependent upon the usage of the hoist and the moisture level of the air supply. ⚠ **CAUTION**

In clean environments e.g. laboratories, paint spray booths, manual drain filters are essential to prevent contamination.

Automatic drain units

These units are automatically self-purging. When the filter bowl is full it will automatically drain itself. Although very convenient to the user, the unit must be sited such that either the purged water is captured by a tray or it purges into an area away from personnel, equipment (particularly electrical equipment) and goods. If contamination from purged water is not a problem then automatic drain units should be selected.

Failure to fit and drain the filter will result in excessive moisture being carried into the hoist valve, motor and brake actuator resulting in internal corrosion and premature failure. ⚠ **DANGER**

LUBRICATOR UNIT

There are two types of lubricator available.

Oil mist lubricator


The preferred type, and essential where the lubricator must be sited some distance from the hoist. The unit produces atomised oil particles which remain in suspension in the air longer.

Droplet Lubricator

Due to the larger particle size of the droplets, these may only be used where the lubricator is close to the coupled hoist.

Failure to fit a lubricator and maintain the correct oil flow will result in rapid wear of the rotor vanes within the motor, excessive heat generation and failure of the air motor within a very short period. ⚠ **DANGER**
Keep the lubricator topped up with a light turbine oil. ⚠ **DANGER**

WORKING PRINCIPLE AND ADJUSTMENT



A portion of the air introduced from the IN side pressurises the lubricant inside the bowl. The remainder of the air passes through the needles (9), and flows to the OUT side. The pressure differential between the inside of the bowl and the inside of the sight dome (2), causes the lubricant inside the bowl into the oil passage (10). The lubricant drips from the dripping tube (11), and lubricate the OUT side. The amount of lubricant is adjusted by the needle (9) on the front face. Turning the needle clockwise increases the amount of lubricant, and turning it counter clockwise until fully opened shuts off the lubricant. The needle on the side that is not used should be left fully opened.



AIR SERVICE EQUIPMENT

REGULATOR UNIT

Most compressors are supplied with a regulator on the output. However, where a number of different pneumatic tools are supplied from the same compressor it is good practice to maintain the supply line or remain at a higher pressure and to fit a regulator to the supply at each tool.

The operating pressures stated for the air hoist are the pressures required at the hoist inlet manifold. Subject to the type of airline, a pressure drop in the line between 0.1 and 0.35 bar (2 and 5 p.s.i) per 10 metres of line should be anticipated (as a result of the frictional resistance of the walls).

MOUNTING / ADJUSTMENT - WARNING

1. Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges. Turning the regulator knob excessively can cause damage to the internal parts.
2. Do not use tools on the pressure regulator knob as this may cause damage. It must be operated manually.

MOUNTING / ADJUSTMENT - CAUTION

1. Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure. Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.
 - ▶ Pull the pressure regulator knob up to unlock. (You can visually verify this with the 'orange mark' that appears in the gap.)
 - ▶ Push the pressure regulator knob down to lock. When the knob is not easily locked, turn it left and right a little and then push it. (When the knob is locked, the 'orange mark', i.e. the gap will disappear.)
2. Pulsation will generate when the difference between the inlet and the outlet pressure is large. In this case, reduce the pressure difference between the inlet and the outlet. Please consult with SMC if pulsation problem is not resolved.
3. When the bowl is installed, install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid dropping or damage of the bowl.




Image for illustration purposes only



LOG BOOK



PNEUMATIC HOIST AND TROLLEY INSPECTION REQUIREMENTS

Pneumatic hoists, trolleys and overhead cranes should be inspected as specified in the 'Supply of Machinery (Safety) Regulations 2008 and The Provision of Use of Powered Machinery (PUWER) S12306 sections 5 & 6 and the results recorded in the log book.

External inspection by a competent person every 12 months or as per the examination scheme. The Lifting Operations and Lifting Equipment Regulations S12306 - 1998.

DAILY OR SHIFT INSPECTION

At the same time each day at the start of each working day of shift operator should carry out a basic inspection of the equipment, its operation and lubrication as required.

MONTHLY OR 3 MONTHLY CHECKS

Depending on the frequency of use and the working conditions, inspection and maintenance should be done at suitable intervals to ensure any deterioration of the equipment will be detected and remedied in good time.

ANNUAL INSPECTION

A competent person with the requisite knowledge of the equipment should carry out a full inspection of powered lifting equipment every 12 months or after any exceptional circumstances which could jeopardize the safety of the lifting equipment. A report should be issued and sent to the customer / employer.

DAILY HOIST AND TROLLEY INSPECTION REQUIREMENTS

The items listed below are intended as a guide for performing daily visual inspections of the components that have a direct bearing on the safety of the hoist and or trolley where the status may change with day to day use. The equipment items listed below do not necessarily need to be restricted to these items, but they should form the basis of the inspection.

OPERATING CONTROLS:	Check for malfunction, excessive wear, broken or damaged components and control function labels.
HOIST CHAIN:	Check chain lubrication, twisted chains (multi fall blocks).
AIR SET:	Check oil level indicator.
SAFETY CATCHES:	Check operation and for damage.
NOISE / OPERATION:	Check for any unusual noise and speeds during function tests.
HOIST OPERATION:	Check the hoist starts and stops quickly.

EXTRA CHECKS FOR TROLLEY

OPERATION:	Check movement and control of the trolley (no load).
TROLLEY MOVEMENT:	Check the trolley moves smoothly along the beam.

CHECKS ON UK Ex / ATEX EQUIPMENT

In addition to the standard checks UK Ex / ATEX hoists and trolleys should also have the following checks carried out:

Check the Bronze, Copper or Zinc coating of the hook is not damaged or worn (or the bottom block for IIC/IIIC equipment).
 Check safety catches.
 Check the UK Ex / ATEX rating on the nameplate is still legible.
 Check the rubber buffers or limits on the trolley are in good condition.
 Check the condition of the Bronze trolley wheels.
 Check the condition and setting of the anti-tip rollers.
 Check air supply lines and control lines for fitting, wear or damage.
 Check load chain for excessive corrosion.
 Check hoist body for excessive corrosion.



PNEUMATIC HOIST AND TROLLEY MAINTENANCE REQUIREMENTS

TO BE CARRIED OUT MONTHLY OR THREE MONTHLY DEPENDING ON THE HOIST WORKING CONDITIONS

DAMAGE:	External inspection of hoist for damage or wear.
HOIST CHAIN:	Check chain lubrication, twisted chains (multi fall blocks) and excessive wear or damaged chain links. (Light mineral oil).
HOOKS:	Check hooks swivel, hook opening and safety catch.
AIR SET:	Check and fill up lubricator bowl and adjust drop rate as required.
FITTINGS/HOSES:	Check all air-line fitting are secure and there are no air leaks.
BOLTS:	Check security of bolts, chain collector and chain anchor.
AIR MOTOR:	Check air motor and silencers - replace as required.
OPERATION:	Function test hoists running speed and control operation without load and then check lifting a load of around 50% of SWL to check brake operation and controls when loaded.
LIMIT SWITCHES:	Check operation of upper and lower limits at slow speed.

EXTRA CHECKS FOR TROLLEY

RUNWAY BEAM:	Check the beam is smooth and flat without obstruction and that the end stops are in place and secure.
DIVE PINION:	Check drive pinion and wheels are fitting correctly and not worn, grease if required.
ADJUSTMENT:	Check flange adjustment, anti tilt roller setting, load bar nuts - adjust or tighten if required,
AIR LINES:	Check security of control lines and supply hoses and fittings.
OPERATION:	Function test over the complete range of travel.
SUPPLY HOSES:	Check air lines are supported and the weight is not hanging from the air set.
TROLLEY CHAIN:	Check geared trolley hand chain and drive.

When detecting any abnormality during inspection due to erroneous use, instruct the operator and user for correct use of the chain hoist.

LOG BOOK

[illegible]

LOG BOOK



MAINTENANCE CHECKS

TO BE CARRIED OUT MONTHLY IN PRODUCTION OPERATIONS WHERE HEAVILY USED OR IN HARSH WORKING CONDITIONS.
TO BE CARRIED OUT THREE MONTHLY WHEN THE HOIST IS ONLY USED OCCASIONALLY.

PLEASE CONTACT RED ROOSTER TO CONFIRM IF MONTHLY OR THREE MONTHLY MAINTENANCE CHECKS ARE REQUIRED IF YOU ARE NOT SURE.

TO BE CARRIED OUT MONTHLY IN PRODUCTION OPERATIONS WHERE HEAVILY USED OR IN HARSH WORKING CONDITIONS.
TO BE CARRIED OUT THREE MONTHLY WHEN THE HOIST IS ONLY USED OCCASIONALLY.

PLEASE CONTACT RED ROOSTER TO CONFIRM IF MONTHLY OR THREE MONTHLY MAINTENANCE CHECKS ARE REQUIRED IF YOU ARE NOT SURE.

[illegible]



RED ROOSTER
LIFTING

Head Office:
Nauta House
The Meadows

Oldmeldrum
Aberdeenshire, AB51 0EZ

T: +44 (0) 1651 872101
E: sales@redroosterlifting.com
W: www.redroosterlifting.com

Depot:
Unit 26
Kelvin Way Trading Estate

Kelvin Way
West Bromwich, B70 7TW

T: +44 (0) 121 525 4162